MASTER INDEX.....01
GEN INFO
WARRANTY PLATE.....01
ALPHA INDEXES
ACCESS.....02
CHASSIS....02
ENGINE
6000.....03
ILLUS.....05
MAN TRANS
7000.....07
PARTS LIST.07
EXTERNAL PARTS.....10
7200.....11
ILLUS.....12
AUTO TRANS
7000.....14
ILLUS.....14
TRANSMATIC
7000.....15
ILLUS.....15
COOL-GRILLE
8000.....16
8546.....17
ILLUS.....18
FUEL-CARB
9000.....19
9300.....20
9510.....20
9600.....21
9622.....22
ILLUS.....23
10000-19999
BODY-S/T
C/REFERENCE
TRANS #4
DSO APPEARS IN FPS 8473-M

INDEX

Notes: A Refer to page 1 of Paint Section

PART NAME	GROUP NUMBER
H — Cont'd	
Housing assy. (heater lower)	18C614
Housing assy. (instrument panel control)	10A858
Housing assy. (instrument panel lamp)	10C876
Housing assy. (P/S drag link control valve & spool)	3C516
Housing assy. (P/S pump)	3A643
Housing assy. (rear axle)	4010-1, 4310
Housing assy. (rear axle power divider front)	4574
Housing assy. (rear axle power divider shift fork)	4563
Housing assy. (steering column shaft coupling)	3A528
Housing assy. (steering gear)	3548
Housing assy. (steering gear actuator)	3E564
Housing assy. (trans. control selector)	7B020
Housing assy. (water pump)	8503
Housing & bearing assy. (clutch pressure plate release bearing)	7A605
Housing & bushing (starter motor drive end)	11130
Housing & plugs assy. (carb. governor)	9B570
Housing & seat assy. (carb. secondary diaphragm)	9501
Housing & shift assy. (power divider diff. lockout)	4563
Housing & wiring assy. (radio speaker)	19A163
Housing kit (rear axle)	4010
Housing kit (starter motor drive end)	11130
Housing kit (trans. rear cross shaft)	7B101
Hub (carb. fast idle cam)	9B558
Hub (trans.)	7931
Hub (trans. clutch)	7B067
Hub (trans. converter impeller)	7915
Hub (trans. output shaft)	7D164
Hub (trans. reverse clutch)	7B067
Hub (trans. third and fourth gear clutch)	7183
Hub (water pump pulley)	8553
Hub assy. (front)	1104
Hub assy. (front spoke wheel)	1014
Hub assy. (P/S pump drive)	3E762
Hub assy. (rear)	1109
Hub assy. (trans. forward ring gear)	7B067
Hub & bearing assy. (clutch release)	7548
Hub & drum assy. (rear wheel brake)	1113
I	
Ignition cable (high tension radio resistance)	12A024
Impeller (water pump)	8512
Impeller assy. (trans. converter)	7908
Impeller repair kit (P/S pump)	3A711
Indicator (eng. oil level)	6750
Indicator (trans. control selector)	7A110
Indicator (trans. oil level)	7A020
Indicator assy. (eng. air cleaner restriction)	9N622
Indicator assy. (eng. stop)	10D846
Indicator assy. (trans. oil temperature)	10C911
Insert (eng. oil filter mounting bolt)	6890
Insert (eng. valve seat)	6057
Insert (fitting)	2A269
Insert (rear spring front hanger)	5A555
Insert (thermostatic choke control air intake)	9A714

PART NAME	GROUP NUMBER
I — Cont'd	
Insert (trans. gear shifter fork)	7C430
Insert (trans. intermediate & high clutch hub)	7A044
Insert (trans. third & high synchronizer clutch hub)	7A044
Installation kit (oil filter)	4A329
Insulation (hood air inlet sound)	16A812
Insulator (alternator diode plate)	10A383
Insulator (alternator rectifier)	10310
Insulator (alternator stator end)	10A361
Insulator (alternator terminal)	10329
Insulator (ammeter)	18C914
Insulator (aux. trans. front & rear mount)	7010, 10726
Insulator (battery hold down)	10726
Insulator (battery hold down clamp)	10774
Insulator (circuit breaker)	12289
Insulator (clutch pedal assist spring)	7A630
Insulator (eng. front support)	6038, 6A061, 6068
Insulator (eng. rear motor mount)	6A061, 6068
Insulator (eng. rear support)	6A061
Insulator (frame to body bracket)	5A103
Insulator (fuel tank)	9240
Insulator (fuel tank strap)	9067
Insulator (hood-sound)	16738
Insulator (horn blowing contact & spring lower)	13867
Insulator (muffler heat)	5B294
Insulator (muffler inlet pipe heat)	5B295
Insulator (non-metallic wiring conduit)	14A240
Insulator (nylon tube)	2B478
Insulator (radiator mounting)	8124-5
Insulator (radiator support brace)	8A421
Insulator (rear spring bracket rebound pin)	5970
Insulator (starter motor field terminal)	11107
Insulator (starter motor grounded brush plate)	11A040
Insulator (starter motor grounded brush spring pin)	11A045
Insulator (starter motor insulated brush plate)	11A041
Insulator (starter motor switch)	11068
Insulator (starter motor switch spring)	11181
Insulator (trans. aux. shaft control tube)	7D260
Insulator (trans. rear mount)	7010, 7E373
Insulator (voltage regulator base)	10547
Insulator assy. (front spring bracket)	5A342
Insulator assy. (rear suspension load)	5899
Insulator assy. (trans. gearshift lever opening cover)	7E398
Insulator kit (starter motor field terminal)	11102
Interior paint	A
Interlock (aux. trans. gearshift rod)	7D161
Insulator assy. (engine air cleaner bracket)	9B929
J	
Jack (radio power feed)	18A930
Jet (carb. governor by-pass)	9973
Jet (carb. main metering)	9533
Jet assy. (windshield washer)	17603