GEN INFO
CHASSIS ALPHA
TRANS #1
ALPHA INDEXES
BODY/S/T...01
ALT-START-DIS
10000.....01
10896.....02
12000.....03
ILLUS.....03
LAMP-WIRING
13000.....04
13415.....05
14405.....06
ILLUS.....07
FENDER-HOOD
16000.....08
ILLUS.....08
SPEEDO-BUMPER
17000.....08
17294.....09
GEARS.....09
17601.....10
ILLUS.....10
HTR-RADIO-A/C
18000.....11
19C705-8...12
ILLUS.....12
BODY-S/M
00000.....13
00006.....14
40252.....15
ILLUS.....18
SOFT TRIM
1980-81....15
1982-84....16
1985-88....17
ILLUS.....18
E/M ILLUS..18
DSO SECTION
GEN INFO...20
CROSS REF..20
PARTS LIST.20
CROSS REF
VENDOR-FORD
INDEX.....23
FORD-VENDOR
1000.....25
3106.....26
4561.....27

DESCRIPTION/RESTRICTIONS	PART NUMBER	ALTERNATOR PARTS LIST -7A THRU 7M											
		A	B	C	D	E	F	G	H	J	K	L	M
BEARING (FRONT)	C9ZZ 10094-A *GE-21	A											
RECTIFIER KIT	E43Z 10304-A *GY-1351	A											
Screw (rectifier to housing)	N803090-S7MA	4											
BEARING (REAR)	D20Z 10A304-A *GE-31	A											
REGULATOR ASSY	E6TZ 10316-A *GR-784-A	A											
Screw (attaches regulator)	N803090-S7MA(AU-64-C)	4											
HOLDER ASSY (BRUSH AND TERMINAL)-incl. brushes	E43Z 10320-A	A											
Screw (brush and terminal)	N803706-S36(AU-64-J)	2											
Nut and washer (brush and terminal)	N621900-S36(AM-29-H)	2											
HOUSING (FRONT)	E6AZ 10333-A *GD-364	A											
HOUSING (REAR)	E6FZ 10334-A *GH-369	A											
Bolt-hex. washer head-no. 10-24 x 2 1/8"	378466-S100(BB-550-D)	3											
ROTOR ASSY	E43Z 10335-A *GM-469	A											
STATOR ASSY	E69Z 10336-B *GC-383	A											
SPRING (BRUSH)	C5AZ 10349-A *GY-913	2											
HOLDER (BRUSH)	★ E43Z 10351-A r/b E43Z 10320-A	A											
RETAINER (FRONT BEARING)	D20Z 10A355-A *GY-693	A											
STOP (ROTOR)	C5AZ 10A360-A	A											
RING (ROTOR STOP)	E6AZ 10370-A *GY-1361	A											

COPYRIGHT © 1987 FORD MOTOR COMPANY DEARBORN, MICHIGAN

ROW 02

ALTERNATOR - STARTER - DISTRIBUTOR - Cont'd

10346 ALT	PARTS LISTS			10896..01	11001-2 STARTER			11002	12000
GEN INFO	103.1..16	103.5..22	103.9	10939..04	GEN	PARTS LIST		...41	ROW
IDENT	103.2..18	103.6..24	..27	10963..06	INFO.36	110.1.46	110.4.59	11650	03
APPL	103.3..20	103.7..25	103.10	10984..08	ID...36	110.2.49	110.5.62	...43	
ROW 01	103.4..21	103.8..26	...28	10998..09	APPL.39	110.3.52			