

MASTER INDEX .....01  
GEN INFO .....01  
ALPHA INDEXES  
ACCESSORIES .....02  
CHASSIS .....02  
REAR AXLE  
SEC 40 .....03  
SEC 40.1  
P/LT/STS .....04  
4000 .....06  
ILLUS .....22  
DRIVESHAFT  
SEC 41-46 .....18  
SEC 46.1-46.1A  
SEC 46.2-46.5  
DRIVE & COUP  
COMPONENTS  
PARTS LIST .....07  
ILLUS .....22  
COUPLING SHAFT  
& INTERSHAFT  
SEC 48  
4800 .....17  
SEC 48.1-48.6  
ILLUS .....18  
FRAME-SPRNG  
EXHAUST  
5000 .....23  
5300 .....23  
ILLUS .....26  
CHASSIS  
6000-9999  
TRANS #3  
CHASSIS  
10000-19999  
BODY-S/TRIM  
VENDOR/FORD  
CROSS REF  
TRANS #4  
DSO APPEARS  
IN  
EPS 8473-M

EXHAUST PARTS LISTS

QTY	PART NUMBER	DESCRIPTION	QTY	PART NUMBER	DESCRIPTION
PARTS LIST NO. 316 - Cont'd			PARTS LIST NO. 318 - Cont'd		
1	004A 5A219-B	Clamp (inlet pipe to engine)	1	0192 5A231-A	Clamp (extension to muffler)
1	004A 5A211-CA	Bracket (inlet pipe to engine)	1	0052 5230-AK	Muffler
1	004Z 5A231-C	Clamp (inlet pipe to connector)	1	0362 5A231-A	Clamp (muffler to bracket)
1	036L 58206-B	Connector	1	004Z 5277-L	Bracket (support)
1	004Z 5A231-D	Clamp (connector to muffler)	1	004Z 5277-G	Bracket (extension to bracket)
1	004Z 5230-C	Muffler	1	0191 5A290-08	Hanger (extension to bracket)
2	036Z 5A215-A	Strap (muffler to frame)	1	004Z 5277-G	Bracket (bracket to frame)
4	0111 5A291-A	Spring (muffler to frame)	1	004Z 5F230-B	Cap (bracket to frame)
1	004Z 5A273-A	Shield (muffler)	1	004Z 5A273-A	Shield (muffler)
1	004Z 5A231-A	Clamp (muffler to outlet pipe)	2	004Z 5C204-A	Clamp (shield to muffler)
1	036Z 5255-C	Pipe (inlet)-lower	1	036Z 5A231-A	Clamp (muffler & outlet pipe to bracket)
1	004Z 5A231-C	Clamp (lower outlet pipe to connector)	1	004Z 5255-A	Pipe (inlet)
1	004Z 58206-D	Connector	1	004Z 5C208-B	Cap (inlet pipe)
1	004Z 5A231-C	Clamp (connector to upper outlet pipe)	1	004Z 5277-L	Bracket (support)
1	004Z 5255-E	Pipe (inlet)-upper-L-LT-LTS models	1	0192 5A273-A	Clamp (extension to muffler)
1	004Z 5255-E	Pipe (inlet)-upper-LR-LRT models	1	004Z 5230-AK	Muffler
1	036Z 5277-L	Bracket (inlet pipe to cab)	1	036Z 5A231-A	Clamp (muffler to bracket)
2	036Z 5A231-B	Clamp (inlet pipe to cab)	1	004Z 5277-L	Bracket (support)
1	036Z 5A273-D	Shield (inlet pipe)	1	004Z 5277-L	Bracket (bracket to frame)
2	07AZ 8287-D	Clamp (shield to outlet pipe)	1	004Z 5F230-B	Cap (bracket to frame)
PARTS LIST NO. 317			PARTS LIST NO. 319		
1	004Z 5A231-F	Clamp (inlet pipe to manifold)	1	0191 5A290-08	Hanger (extension to bracket)
1	036Z 5246-W	Pipe (inlet)-upper	1	004Z 5A273-A	Shield (muffler)
1	011Z 5A211-CA	Clamp (inlet pipe to inlet pipe)	1	004Z 5C204-A	Clamp (shield to muffler)
1	004Z 5230-AE	Pipe (inlet)-lower	1	036Z 5A231-A	Clamp (muffler & outlet pipe to bracket)
1	004Z 5276-Y	Bracket (inlet pipe to clutch pedal)	1	004Z 5255-A	Pipe (inlet)
1	011Z 5A231-A	Clamp (inlet pipe to clutch pedal)	1	004Z 5C208-B	Cap (inlet pipe)
1	004Z 5A231-C	Clamp (inlet pipe to connector)	1	004Z 5A231-F	Clamp (inlet pipe to engine)
1	036Z 58206-A	Connector	1	004Z 5246-W	Pipe (inlet)
1	004Z 5A231-C	Clamp (connector to muffler)	1	036Z 5A231-F	Clamp (inlet pipe to connector)
1	004Z 5230-D	Muffler	1	004Z 58206-B	Connector
2	036Z 5A215-A	Strap (muffler to frame)	1	011Z 5A231-F	Clamp (connector to extension)
4	0111 5A291-A	Spring (muffler to frame)	1	004Z 5A212-W	Extension-Y type
1	004Z 5A273-A	Shield (muffler)	Right hand side		
1	004Z 5A231-A	Clamp (muffler to lower outlet pipe)	1	011Z 5A231-F	Clamp (extension to connector)
1	036Z 5255-C	Pipe (inlet)-lower	1	004Z 58206-C	Connector
1	004Z 5A231-C	Clamp (lower outlet pipe to connector)	1	011Z 5A231-F	Clamp (connector to extension)
1	004Z 58206-D	Connector	1	004Z 5A212-0K	Extension
1	004Z 5A231-C	Clamp (connector to upper outlet pipe)	1	036Z 5A231-A	Clamp (extension to muffler)
1	004Z 5255-E	Pipe (inlet)-upper-L-LT-LTS models	1	036Z 5230-D	Muffler
1	004Z 5255-E	Pipe (inlet)-upper-LR-LRT models	1	036Z 5A231-A	Clamp (muffler to bracket)
1	036Z 5277-L	Bracket (inlet pipe to cab)	1	004Z 5277-L	Bracket (support)
2	036Z 5A231-B	Clamp (inlet pipe to cab)	1	0191 5A290-08	Hanger (extension to bracket)
1	036Z 5A273-D	Shield (inlet pipe)	1	004Z 5A231-C	Clamp (extension to bracket)
2	07AZ 8287-D	Clamp (shield to outlet pipe)	1	004Z 5277-L	Bracket (bracket to frame)
PARTS LIST NO. 318			PARTS LIST NO. 320		
1	054Z 5A231-F	Clamp (inlet pipe to engine)	1	004Z 5F230-B	Cap (bracket to frame)
1	004Z 5246-W	Pipe (inlet)	1	004Z 5A273-A	Shield (muffler)
1	011Z 5A231-B	Clamp (inlet pipe to connector)	2	004Z 5C204-A	Clamp (shield to muffler)
1	004Z 58206-B	Connector	1	036Z 5A231-A	Clamp (muffler & inlet pipe to bracket)
1	011Z 5A231-B	Clamp (connector to extension)	1	004Z 5255-B	Pipe (inlet)
1	004Z 5A212-0H	Extension-Y type	1	004Z 5C208-A	Cap (inlet pipe)
Left hand side			Left hand side		
1	011Z 5A231-F	Clamp (extension to connector)	1	011Z 5A231-F	Clamp (extension to muffler)
1	004Z 58206-C	Connector	1	036Z 5230-D	Muffler
1	011Z 5A231-B	Clamp (connector to extension)	1	036Z 5A231-A	Clamp (muffler to bracket)
1	004Z 5A212-A	Extension	1	004Z 5277-L	Bracket (support)
1	004Z 5A212-A	Extension	1	004Z 5277-G	Bracket (bracket to frame)

ROW 24	EXHAUST SYSTEMS - 60000			
	GEN INFO	S176 CHART	C78EV CHART	PARTS LISTS
	APPL CHART 23-52	52127..23-37	52127..23-38	5300
		5230..23-39	5230..23-38	INDEX ROW 25
		5246..23-43	5246..23-41	..01
	5255..23-40	5255..23-42		