

1 1 - 1 6
 1973/79
 TRUCK SERIES 600/900

SECTION 72 13

MASTER INDEX.....01
GEN INFO.....01
WARRANTY.....01
PLATE.....01
ALPHA INDEXES
ACCESS.....02
CHASSIS.....02
ENGINE
6000.....03
ILLUS.....05
TRAN TRANS
7000.....07
PARTS LIST/07
EXTERNAL
PARTS.....10
7200.....11
ILLUS.....12
AUTO TRANS
7000.....14
ILLUS.....14
TRANSMATTC
7000.....15
ILLUS.....15
COOL-GRILLE
8000.....16
B546.....17
ILLUS.....18
FUEL-CARS
9000.....19
9300.....20
9510.....20
9600.....21
9622.....22
ILLUS.....23
10000-19999
BODY-S/T
C/REFERENCE
TRANS #4
D50 APPEARS
IN
FPS 8473-M

YEAR	MODEL / RESTRICTIONS	TRANS SPD	TYPE	PART NUMBER	DESCRIPTION	QTY.
74111 BRACKET (AUXILIARY TRANSMISSION MOUNTING FRONT)						
73/	L-LT-L7000/900	3&4	Acc.	0042 74311-A	9 3/4" x 8 3/8" x 5/16" thick-see w/Draw (Option) 7041, 7231, 8031 and 8341 trans.	1
74/	L7000 -- diesel	3&4	Acc.			1
75/	C-CT800/900 -- 8 cyl gas 875,877,878	A8				1
75/76	L-LT-L7000 -- 8 cyl	3	Acc.	0042 74311-B	11 3/8" wide x 5/16" thick-see w/Draw (Option) 8031 trans.	1
76/	L7000 -- diesel	3&4	Acc.	0482 74311-A	#0484 74311-AA-"Y" shape-12 1/8" wide and x 4 7/8" narrow end x 12 1/16" long x 1/4" thick	1
74/	L87000/900 -- gas	4	Acc.			1
73/	L400, L7000/900	3&4	Acc.	352914-50	180-900-600 front bracket to transmit-see head 8000 and 3/4"-16 x 3 1/2"	2
73/	L400, L7000/900	3&4	Acc.	374312-50	180-900-0-600 front bracket to transmit-3/4"-16 x 3 1/2"	2
73/	L400, L7000/900	3&4	Acc.	354004-5	112-1200-weather-40-3/4"	2
73/	L400, L7000/900	3&4	Acc.	261126-5	100M-47-rod-weather-5/4"-36	2
73/	L400, L7000/900	3&4	Acc.	72072-5	30-40-rod-rod-4-1/2" x 1 1/2"	2
78312-2 Refer to Transmission Parts List Section 70, page 1						
73112 VALVE BODY (TRANSMISSION CONTROL)-see refer to Draw 7312						
73/	C700/900, L-LB-L87-L7000/900	10		5312 7312-A	On gearshift lever	1
73/77	W-W7000	10				1
73/	LNT-LT-L7000 -- diesel	7				1
76/	L-LB-LNT-L7000 3&4 Det. Del.	A8				1
74/77	W-W7000 -- 5&6 Detact diesel					1
74/	L-L7000 -- 8 cyl 893 Cal.	A8				1
74/	L-LB-LNT-LT-LTS -- 890 Com. 3,7-M					1
74/77	W-W7000 -- 890 Com.					1
77/	LT-LNT-LTS 900 -- diesel	8				1
78/	CT-CL7000	5,10				1
74	LT-L7000 -- diesel	13		0402 7312-A	1/8"-24 thread Use w/Filler 413 trans.	1
	LT-L7000 -- gas					1
	"Refer Sec. 106,061"					
74/	C-CT-L-LB-LNT-LT-L7000 -- 10, Gas	10,				1
	C-CT-LB-LNT/600/900, L-LT-L7000 -- diesel					1
74/77	L7000	13				1
74/	L87000 -- 104 Cal. diesel	12				1
73/	B-C-F400/900			0472 7312-A	Used as control valve for air brakes Use W/Filler 870 900LL trans Jump reduction shift valve	1
77/	LS-LNT-L7000 -- diesel	8				1
74/77	L-L7000 -- diesel	10		0402 7312-B	Use w/Draw (Option) 5371010-2A trans.	1

NOVEMBER, 1982

©COPYRIGHT © 1982

FORD MOTOR

—DISTRIBUTION DIVISION

INDEX

CHANGE 6

ROW 11	MANUAL TRANSMISSION - Cont'd						
	7201..02	7229..13	GEN INFO...23	GEAR SHIFT YONGERS	7500...37	7552..52	ILLUS
	7206..03	7286..15	TSL C/REF..23	PARTS LISTS	7511...40	7576..55	INDEX
	7211..09	7316..18		2A-2M..25	4A-4M..29	7521...43	7598..58
	7220..11	7476..21		3A-3M..26	4N-4Z..32	7550...48	7961..62
				3N-3Z..28			