

0 1 - 1 1

10

GENERAL
INFORMATION1973/79
TRUCK SERIES 600/900

GROUP NUMBERS and RELATED PART NAMES and CATALOG SECTIONS

MASTER INDEX.....01
GEN INFO WARRANTY PLATE.....01
ALPHA INDEXES
CHASSIS.....02
BODY.....02
SOFT TRIM.....02
ALT-STRT-DIST
10000.....03
11000.....04
12000.....05
ILLUS.....05
LAMP WIRING
13000.....07
14303.....08
ILLUS.....09
FENDER-ROCK
16000.....10
ILLUS.....10
SPEEDO-NUMBER
17000.....11
GEARS.....11
17601.....13
ILLUS.....13
HYD-RADIO-A/C
18000.....14
ILLUS.....15
BODY
00000.....16
10034.....17
BODY BOLTS
.....17
ILLUS.....20
SOFT TRIM
1973/78.....18
1977/79.....19
ILLUS.....20
EXT MOUNTS
ILLUS.....20
C/REFERENCE
VENDOR-FORD
INDEX.....22
FORD-VENDOR
1000.....24
3134.....25
4428.....26
7267.....27
DSO APPEARS IN FFS 8473-M

GROUP NUMBER RANGE	PART NAME	CATALOG SECTION NUMBER
7000 - 7000	Manual transmission identification chart	70
7000 - 7000	Manual transmission parts lists - Auxiliary Spicer	70.2
	Manual transmission parts lists - 4 speed New Process	70.3
	Manual transmission parts lists - 4 speed Warner	70.7
	Manual transmission parts lists - 5 speed New Process	70.8
	Manual transmission parts lists - 5 speed Clutch	70.9
	Manual transmission parts lists - 5 speed Fuller	70.10
	Manual transmission parts lists - 5 speed Spicer (3000 and 6000 Series)	70.11
	Manual transmission parts lists - 5 speed Spicer (3000 Series)	70.12
	Manual transmission parts lists - 10 speed Fuller	70.14
	Manual transmission parts lists - Rockwell (Dimpled) transfer case	70.17
	Manual transmission parts lists - 6 speed Fuller	70.18
	Manual transmission parts lists - 12 speed Fuller	70.19
	Manual transmission parts lists - 18 speed Spicer	70.20
	Manual transmission parts lists - 7 speed Spicer	70.21
	Manual transmission parts lists - 10 speed Spicer	70.22
	Manual transmission gasket set and repair kits	70A
7000 - 7000	Manual transmission linkages, etc.	71
7200 - 7200	Manual transmission linkages, etc.	72
7000 - 7000	Automatic transmission identification chart	A70
7000 - 7000	Automatic transmission parts lists - CB	A70.4
7000 - 7000	Automatic transmission linkages, etc.	A71
7000 - 7000	Transaxle transmission identification chart	T70
7000 - 7000	Transaxle transmission linkages, etc.	T71
7000 - 7000	Transaxle transmission parts lists	T70.1
7000 - 7000	Manual transmission gearshift lower parts lists	T2.1, T2.2, etc.
7300 - 7400	Manual transmission gearshift mechanisms	T3
7500 - 7900	Clutch	T5
8000 - 8400	Radiator, grille and cooling	80
8500 - 8500	Water pump	83
8600 - 8900	Fan	86
9000	Drive belt identification chart	90
	Drive belt application chart	90
9000 - 9200	Fuel tank and lines	90
9300 - 9300	Fuel pump and gear	92
9400 - 9400	Mufflers	92
9500	Carburetor identification chart	95
9500	Carburetor application chart	95
9500 - 9500	Carburetor parts lists	95.19, 95.20, etc.
9600	Air cleaner application chart	96
9600	Air cleaner identification chart	96
9600 - 9600	Air cleaner parts and related parts	96
9700 - 9800	Choke and fuel-injector	96
9800 (S&S)	Carburetor gasket set and tune-up kits	95A
9900		
10040	Alternator application chart	103
10000 - 10000	Alternator, pulleys and mounting parts	103
10000	Alternator identification chart	103
10000 - 10000	Alternator parts lists	103.1, 103.2, etc.
10000 - 10000	Battery and instrument cluster parts	103
11000 - 11000	Starter, ignition switch and headlamp switch	110
10001	Starter identification chart	110
11001 - 11000	Starter parts lists	110.1, 110.2, etc.

NUMBER	GENERAL INFORMATION		WARRANTY PLATE INFORMATION			
	MASTER INDEX.....01	GEN INFO TEXT...02 ILLUS...65	ASSY PLANT...44 BODY ILLUS...54 BODY TYPE...51 DIAGRAM...36	DISTRICT...64 ENGINE...41 FRONT AXLE...63 G.V.W....64	MODEL.....45 REAR AXLE...58 SERIAL NO...44 SERIES.....40	TRANS.....56 TRIM.....51 TSL off...17 WHEEL BASE...44