

GEN INFO.....01
ALPHA INDEX
ACCESS.....02
CHASSIS.....02
7.9K-XP6-EX
5000.....03
5300.....04
5516.....05
ILLUS.....06
ENGINE
6000.....08
ILLUS.....10
MAN TRANS
7000.....11
EXT PARTS..14
GEARSHIFT
TOWERS.....15
7500.....15
ILLUS.....16
TRANSMATIC
7000.....18
ILLUS.....18
COOL-GRILLE
8000.....19
8600.....20
ILLUS.....21
FUEL-CARD
9000.....22
9300.....23
9500.....24
9600.....25
ILLUS.....26
10000 THRU
SHEET METAL
TRANS #3
D50-VOR TO
FORD-C/REF
TRANS #3

SECTION 72

1980/  
TRUCK SERIES 600/900

YEAR	MODEL / RESTRICTIONS	TRANS		PART NUMBER	DESCRIPTION	QTY
		SFO	TYPE			
<b>7A312-2 MOD AUXILIARY TRANSMISSION GEAR SHIFT CONTROL CONNECTING -- ConvY</b>						
80/	LNT800 -- diesel	364	Ass.	DWZ 7A312-B	R.R. - #DWZ 7A312-BA-074" dia. rod's 24 3/4" long incl. drive-rod w/Dana (Special 8001 and 8341 trans. L.S. - #2494 7A312-BA	1
82/	LN-LNT600/900 -- Cat. 3208 Turbo	4	Ass.	DWZ 7A312-B E2WZ 7A312-B	R.R. - #E2WZ 7A312-BA incl. drive-rod w/Dana (Special 8340 trans. L.S. - #E2WZ 7A312-BA	1
78313-7316 Refer to Transmission Parts List Section 70, page 1						
<b>77324 SHIELD ASSY. (TRANSMISSION MOOSE INSULATOR)</b>						
80/	CL-CL7000 -- 548 Del. Del.	AS	AS	DWZ 77324-K	R.H.	1
80/81	CL-CL7000 -- 548 Del. Del.	AS	AS	DWZ 77324-L	Lower	1
80/81	L75000 -- 426 Del.w/straps w. 280000 type frame	AS	Fuller	DWZ 77324-B DWZ 77324-B	R.H.-R.R. 141(1) L.H.	1
80/	LN-LNT900 -- 548 Del. (8V-717) w/straps w. drop type frame	AS	Fuller	DWZ 77324-E	R.H.	1
80/	LN-LNT900 -- 552 Del. (8V-92)	AS	AS	DWZ 77324-F	L.H.	1
80/	L-L7-L8-LNT900 -- 548 Del. 18-VT18 & 8-VT17T 426 Del. & 893 Cat.	AS	Fuller	DWZ 77324-L DWZ 77324-M	R.H. L.H.	1
81/	L71900	AS	AS			1
80/	L-L7-L7S-LN-LNT900 -- 893 Cat. 426 Del. & 548 Del. 18-VT18 & 8-VT17T)- w/o 100 gal. fuel tank	AS	Fuller	DWZ 77324-J	Lower	1
80/	LN-LNT900 -- 552 Del. 18V-92)	AS	AS			1
82/	L71900	AS	AS			1
80/	LN-LNT900 -- 548 Del. (8V-717)	AS	Fuller	DWZ 77324-N	Lower	1
80/	LN-LNT900 -- 552 Del. (8V-92)	AS	AS			1
80/	L-L7900 -- All models with 100 gal. fuel tank	AS	AS	DWZ 77324-P	Lower rear	1
82/	L71900	AS	AS			1
80/	L-L7900 -- All models with 100 gal. fuel tank	AS	AS	DWZ 77324-B	Lower front	1
82/	L71900	AS	AS			1
78320-7325 Refer to Transmission Parts List Section 70, page 1						
<b>77325 BRACKET ASSY. (TRANSMISSION INSULATOR SHIELD)</b>						
80/	CL-CL7000	AS	AS	DWZ 77325-A		1
<b>77327 BRACE (TRANSMISSION MOOSE INSULATOR SHIELD)</b>						
80/	CL-CL7000	AS	AS	DWZ 77327-A		1
7328-78321 Refer to Transmission Parts List Section 70, Page 1						
<b>78322 COVER (TRANSMISSION REAR CROSS SHAFT (SHIELD) - refer to Trans. Parts List Sect. 70, Page 1)</b> Also refer to 72.1 thru 72.4 Parts List						
<b>78323 BRACKET (TRANSMISSION SHIFT LEVER SHAFT) - Also refer to Trans. Parts List Sect. 70, Page 1</b>						
80/	L7-L75800/900/LNT800	13		DWZ 78323-A	# 14914	1
80/	C-CT-4-LN-LNT-L7-L75800 Gen. C-CT-LN-LNT600/900 L-L7-L75800 -- diesel	10				1
78325 Refer to Transmission Parts List Section 70, page 1						
<b>7490 SHAFT (TRANSMISSION GEARSHIFT SOCKET)</b>						
80/	CL-CL7000	AS	AS	DWZ 7490-A		1
7840-2 Refer to Transmission Parts List Section 70, page 1						

HOW TO	MANUAL TRANSMISSION-Cont'd	EXTERNAL PARTS
	13A-13M 13/S FULLER..01	TRANS 7002.43 7146.57 7316
	13N-13Z 13/S FULLER..14	REPAIR 7047.46 7201.60 .67
	15A-15M 15/S FULLER..27	KITS 7086.50 7220.62 7375
	.....37	7095.55 7286.65 .69