

|                    |  |
|--------------------|--|
| GEN INFO           |  |
| CHASSIS ALPHA      |  |
| TRANS #1           |  |
| ALPHA INDEXES      |  |
| BODY-5/Y...01      |  |
| ALT-START-015      |  |
| 10000.....01       |  |
| 10896.....02       |  |
| 12000.....03       |  |
| ILLUS.....03       |  |
| LAMP-WIRING        |  |
| 13000.....04       |  |
| 13415.....05       |  |
| 14405.....06       |  |
| ILLUS.....07       |  |
| FENDER-HOOD        |  |
| 15000.....08       |  |
| ILLUS.....08       |  |
| SPEEDOMETER-BUMPER |  |
| 17000.....08       |  |
| 17294.....09       |  |
| GEARS.....09       |  |
| 17601.....10       |  |
| ILLUS.....10       |  |
| HYD-RADIO-A/C      |  |
| 18000.....11       |  |
| 19C705-8...12      |  |
| ILLUS.....12       |  |
| BODY-5/M           |  |
| 00000.....13       |  |
| 00006.....14       |  |
| 40252.....15       |  |
| ILLUS.....18       |  |
| SOFT TRIM          |  |
| 1980-81....15      |  |
| 1982-84....16      |  |
| 1985-88....17      |  |
| ILLUS.....18       |  |
| E/M ILLUS...18     |  |
| ISO SECTION        |  |
| GEN INFO...20      |  |
| CROSS REF...20     |  |
| PARTS LIST...20    |  |
| CROSS REF          |  |
| VENDOR-PORD        |  |
| INDEX.....23       |  |
| FORD-VENDOR        |  |
| 1000.....25        |  |
| 3106.....26        |  |
| 4561.....27        |  |

THIS PAGE  
INTENTIONALLY LEFT  
BLANK

| ROW#      | FENDER - HOOD |           |              | SPEEDOMETER - BUMPER |           |           |
|-----------|---------------|-----------|--------------|----------------------|-----------|-----------|
|           | 16000..06     | 16575..15 | 16842..03    | ILLUSTRATION         | 17001..58 | 17266..67 |
| 16005..09 | 16628..17     | 16920..24 | INDEX.....01 | 17299..60            |           | ROW       |
| 16078..11 | 16702..19     |           |              | 17260..60            |           | 09        |
| 16458..13 | 16740..21     |           |              | 17262..66            |           |           |