

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP

Sales Code:	Option:	R_D:	SCDesc:
AAAC00	0002	R	VEHICLE DESIGNATION,TRUCK
AAAF00	0006	R	VEHICLE SERVICE,ON/OFF HIGHWAY
AAA800	0002	R	VEHICLE APPLICATION,CONSTRUCTION,END-DUMP,-
ABBS00	0001	R	SERIES DESCRIPTION,LT8511 LOUISVILLE 8500,111" BBC 6X4
ACAA00	0002	R	TERRAIN,MAX 10% OFF-HIGHWAY,TERRAIN
ADAB00	0002	R	ROAD SURFACE,TYPICAL HIGHWAY,-
A07500	0071	R	AFTER FRAME,75 IN.
SCAK90	0001	R	PAINT - SOLID COLOR,VERMILLION,-,-
SP4300	0001	D	PAINT - SPOB OPTION, 43, SUN VISOR
TFAT00	0060	R	TIRE SIZE-FRONT,315/80RX22.5-18,RADIAL,315/80,X22.5,-18
TRAJ00	0107	R	TIRE SIZE-REAR,11RX22.5-14,RADIAL,11,X22.5,-14
W21400	0022	R	WHEELBASE,214 IN.
10AF00	0074	R	AXLE, FRONT,16000 LB,FORD,-,STEEL,-
11GJ00	0025	R	REAR AXLE,TANDEM,46000,ROCKWELL,RT-46-160,5.38,STD TRACK,STL
13AB00	0051	R	SHOCK ABSORBERS - FRONT,-,-
13AF00	0024	R	DRAG LINKS & TIE RODS,GREASEABLE
13AW00	0164	R	DIFFERENTIAL,DRV CONTR LOCKING MAIN
13BT00	0074	R	STEERING,POWER
13F300	0007	R	AXLE LUBE,REAR SYNTHETIC,-,75W90
13H700	0002	R	WHEEL SEALS FRONT,-,GREASE
13171H	0002	R	JOINT SIZE,1710 HD,-
16A000	0168	R	BRAKES-REAR,AIR CAM,-,16.5" X 7",-
16A200	0064	R	BRAKES-FRONT,AIR CAM,-,16.5" X 6",-
19FC00	0053	R	AIR COMPRESSOR,13.2 CFM,WATER,BENDIX,-
19JE00	0022	R	DUST SHIELDS,-
19NK00	0013	R	ANTI-LOCK BRAKE,DELETE
19NL00	0002	R	AIR RESERVOIR,STEEL
19N000	0001	R	PARKING BRAKE,AIR,MAXI,-,4 WHEEL,-,-
22B000	0013	R	CAB,STEEL,PRESTIGE,MEDIUM GRAPHITE
23AB00	0022	R	HOOD,TILTING
23BP00	0024	R	MIRROR BRACKETS,102" ARMS
23CX00	0037	R	HORNS - AIR,DUAL,HADLEY,-,DUAL BASE RECT,-
23DD00	0006	R	SUN VISOR - EXTERIOR,FIBERGLASS
23KH00	0004	R	HORNS - ELECTRIC,SINGLE
23YL00	0009	R	REAR WINDOW,FIXED-SOLAR TINTED
23YY00	0011	R	MIRRORS - DUAL,WESTERN,-,STAINLESS,-,-
23Y900	0013	R	MIRRORS - CONVEX,DUAL,-,8",STAINLESS,-,-
232R00	0002	R	HOOD ACCENT BAR,BRIGHT
233C00	0004	R	HEADLAMP BEZELS,BRIGHT
24AJ00	0080	R	AIR CONDITIONING,-
24AL00	0034	R	CIGAR LIGHTER,DASH MOUNTED
24B500	0008	R	STEERING WHEEL,18 IN DIA,-
24H200	0009	R	RADIO AM/FM STEREO,W/CSTE & WEATHER BAND,-,-
24KD00	0009	R	STEERING COLUMN,ADJUSTABLE TTLT

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
24K700	0008	R	CONSOLE STORAGE HEADER,MOUNTED				
25AAC4	0037	R	SEAT - DRIVER,INDIV,BOSTROM,HIBACK,AIR-T915,AIR,-,-				
25AAC5	0009	R	SEAT - PASS,INDIV,NATIONAL,MID-BACK,-,FIXED ECONOMY NON-ADJ,LESS ISOL				
25AADV	0010	R	LUMBAR SUPPORT DRIVER,AIR				
25AADX	0019	R	MAP POCKET DRIVER,BACK OF SEAT				
25AAD3	0002	R	SEAT BELTS DRIVER,LAP & SHOULDER,3-PT. MOUNTING,W/ADJUSTABLE D-RING				
25AAD9	0001	R	SEAT - TRIM,POLYKNIT VINYL (CLOTH),,-				
25AAEF	0017	R	SEAT COVERS BASE DR,AIR SEAT SUSPENSION,-				
25AAT0	0001	R	SEAT BELTS PASS,LAP & SHOULDER,3-PT MOUNTING,W/ADJUSTABLE D-RING				
26MR00	0002	R	GAUGES-AIR RESTRICTION,-,AIR CLEANER MTD,-				
26MY00	0012	R	SWITCH-TURN SIGNAL,SIGNAL STAT,NON-CANCELLING				
26M500	0007	R	WARN LTS & CHIME,LOW OIL PRES,LOW COOL LEVEL,HI COOL TEMP,HI ENG OIL				
26M700	0002	R	GAUGES RH CONTROL PANEL,FLAT GAUGE INSERT				
26NN00	0005	R	GAUGES,ELECTRONIC,INST. CLUSTER				
28B300	0030	R	ALTERNATOR,DELCO,100 AMP,-,INTGL,-				
29GM00	0036	R	BATTERIES,2,12V,MOTORCRAFT,900 CCA,96 AMP,GROUP 31,STUD TYPE				
29KF00	0271	R	BATTERY BOX,-,LH FRAME MTD AFT OF CAB				
30TF00	0017	R	ENGINE,DIESEL,CUMMINS MID-RANGE,C8.3,-,275 HP,2200 RPM,800 FT LBS TOR				
32FP00	0025	R	EXH,SVOT,TRNSV HORZ,-, MUFFLER,PLAIN,VERTICAL OUTLET,CAB MTD,-				
36AM00	0050	R	CLUTCH,14,SPICER,2-PLT,-,DMP CER,1.75 SPL,PULL,-,-,-,900				
36CC00	0009	R	REMOTE LUBE FITTING,FOR CLUTCH T/OUT BRG				
37AN00	0068	R	COOLING - EXTRA,-				
37WH00	0022	R	AIR INTAKE HEATER,-				
373X00	0009	R	DIRT SCREEN,GRILLE MTD DIRT FILTER				
373000	0021	R	ENGINE MOUNTS,COMPRESSION ENG MOUNTS,-				
373200	0006	R	ENGINE SHUTOFF CONTROL,IGNITION KEY,-				
373400	0018	R	FAN CLUTCH,EATON VISCOUS,-,-				
40EN00	0002	R	FRAME ENDS,REAR SQUARE CUT,-,-				
40FD00	0023	R	FRAME,30.0 SM,120000 PSI,OUTSD FULL CHNL REINF,STL,ALL-BOLTED,10.88				
43QM00	0006	D	FUEL TANKS,DUAL,50 GAL,LH CYL 24",STL,50 GAL,RH CYL 24",STL,-				
44HW00	0013	D	FUEL TANK DRAW,DU/DU RETURN W/O C/O				
46CY00	0010	R	SUSPENSION FRONT,16000 LBS,-,-,MULTI-LEAF 54" SPREAD,-				
47KV00	0029	R	REAR SUSPENSION -TANDEM,46000 LBS,NEWAY,AD-246,AIR RIDE,54",-,-,T/T-A				
48AC00	0043	R	AIR BAG DUMP VALVE,IN CAB,-,FULL AIR OPERATED				
50XA00	0010	R	TIRES FRONT,LOW PRO TUBELESS,RADIAL,315/80,X22.5,-18,GOODYEAR,UNISTEE				
51E400	0015	R	TIRES REAR,TUBELESS,RADIAL,11,X22.5,-14,GOODYEAR,UNISTEEL G124,498 RP				
52HB00	0020	R	WHEELS FRT,22.5,X9.00,10H,-,-,STEEL,1PC,5 HH,-,-,285MM ISO,-,5.25, 90				
53G000	0025	R	WHEELS RR,22.5,X8.25,10H,-,-,STEEL,1PC,5 HH,-,-,285MM ISO,-,6.19, 730				
55CX00	0017	R	NUT COVERS REAR,BRIGHT				
55CZ00	0017	R	HUB COVERS REAR,BRIGHT				
56P200	0011	R	TRANSMISSION,MANUAL,FULLER,RTO 11908LL,10 SPD,.74,16,1150				
57BC00	0013	R	TRANS LUBE,SYNTHETIC 50W				
59AB00	0041	R	TOW HOOKS-FRONT,-				
59HR00	0001	R	BUMPER,FLAT-FULL WIDTH,STEEL CHROME-PLATED,-				
62AA00	0003	R	TRANSPORTATION,DRIVE AWAY				
647V00	0002	R	WARRANTY COVERAGE CODE,7V				

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP

R_D:	PartNo:	Qty:	ServPart:	PartDesc:	DsoOpt:
R	BUCKS-A-DAY	1		TEST PART	
D	NO-ADD-PARTS	448		TESTPARTS	DL:
R	F3HT-1015-EA	8	F3HZ-1015-E	DISC WHEEL 22.5 X 8.25 10	
R	F5HT-1015-AB	2	F4HZ-1015-G	DISC WHEEL 22.5X9.0 10H I	
R	F5HT-1102-MA	2		HUB/DRUM ASSY FR 10H ISO	
R	F6HT-1113-GA	4		HUB & BRK DRUM ASY RR	
R	D3HA-1131-AA	2	D5HZ-1131-A	CAP-FRT HB GRSE	
R	TAKAA-1142-A	32	B8QH-1142-B	ADAPTER-RR WHL HUB STUD	
R	E9HT-1144-AA	4	E9HZ-1144-A	GSKT-RR AX SHFT	
R	FOHT-1153-CA	2		GSKT-FRT HB GRSE CAP	
R	E1HT-1175-AA	4	F2HZ-1175-C	SEAL ASSY-WHEEL	
R	D3HA-1190-BA	2		RETAINER ASY FRT WHL HUB	
R	C5TA-1201-A	2	C5TZ-1201-A	CNE & RLR ASY-FRT WHL INR	
R	C5TA-1216-A	2	C5TZ-1216-A	CNE & RLR ASY-FRT WHL OTR	
R	TAJAA-1240-A	4	B8QH-1240-B	CONE & ROLLER ASY OTR	
R	D7HA-1244-AA	4	D7HZ-1244-A	CONE & ROLLER ASY INR	
R	TEST-1460-275LO	1		TEST 275LO 1460	
R	D5HA-1508-FA0209	8		CASING - TIRE 11R22.5 (G)	
R	E3HT-1508-DA0203	2		TIRE 315/80R22.5J G291	
R	TYBD-1700-C	10		VALVE	
R	F8HT-2010-RA	1		BRAKE ASSY - FRT - R.H.	
R	F8HT-2011-RA	1		BRAKE ASSY - FRT - L.H.	
R	F8HT-2025-DB	2		CHAMBER ASY-FRT WHL TYPE	
R	F6HT-2063-NB	1		RESERVOIR ASY - BRAKE	
R	F6HT-2063-RB	1		RESERVOIR ASY - BRAKE	
R	F6HT-2063-TB	1		RESERVOIR ASY - BRAKE	
R	F3HT-2073-BA	1	F3HZ-2073-A	BRACKET-RR WHL JOUNCE HOS	
R	E7HS-2074-JA	8	FOHZ-2074-A	CONN-RR WHL BRK TUBE	
R	F6HT-2078-AA	2		HOSE ASY FRT WHL BRK RH	
R	F6HT-2084-AD	2		CLAMP ASSY - AIR RESVR MT	
R	F6HT-2084-BD	4		CLAMP ASSY - AIR RESVR MT	
R	F8HT-2209-NB	1		BRK ASY-FWD RR-RH PATT1	
R	F8HT-2209-RA	1		BRK ASY-RR REAR-RH PATT1	
R	F8HT-2210-NB	1		BRK ASY-FWD RR-LH PATT1	
R	F8HT-2210-RA	1		BRK ASY-RR REAR-LH PATT1	
R	F8HT-2225-DB	4		CHMB ASY-RR WHL BRK AIR	
R	F6HT-2282-EA	2		HOS ASY-RR WHL BRK	
R	F8HT-2282-SA	1		HOS ASY-RR WHL BRK	
R	F8HT-2314-AA	2		SLACK ADJUSTER / AUTO /	
R	F8HT-2314-BA	4		SLACK ADJUSTER / AUTO /	
R	F6HT-2320-LD	1		BRACKET-BRAKE RESVR. MTNG	
R	F6HT-2320-HE	1		BRKT ASY-BRAKE RESVR MTNG	
R	F6HT-2320-JE	1		BRKT ASY-BRAKE RESVR MTNG	
R	F6HT-2320-KD	1		BRKT ASSY-BRAKE RESVR. MT	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F6HT-2457-AA		1			PAD-PDL	
R	F8HT-2467-AA		1			BRKT ASY-BRK PDL	
R	F7HT-2535-DA		1			FTG BRK MANF-AIR	
R	F6HT-2535-KA		3			FTG BRK MANF-AIR	
R	F6HT-2535-LA		3			FTG BRK MANF-AIR	
R	F6HT-2535-MA		1			FTG BRK MANF-AIR	
R	F6HT-2535-RA		2			FTG BRK MANF-AIR	
R	F6HT-2535-TA		2			FTG BRK MANF-AIR	
R	F6HT-2535-UA		6			FTG BRK MANF-AIR	
R	F7HT-2535-BA		1			FTG BRK MANF-AIR	
R	F6HT-2535-NA		1			FTG BRK MANF-AIR	
R	F8HT-2535-BA		3			FTG BRK MANF-AIR	
R	F8HT-2535-CA		2			FTG BRK MANF-AIR	
R	F8HT-2535-DA		2			FTG BRK MANF-AIR	
R	F8HT-2535-FA		2			FTG BRK MANF-AIR	
R	F8HT-2535-JA		2			FTG BRK MANF-AIR	
R	F8HT-2535-KA		2			FTG BRK MANF-AIR	
R	F6HT-2535-JA		1			FTG BRK MANF-AIR	
R	F7HT-2535-AA		1			FTG BRK MANF-AIR	
R	F6HT-2535-ABAA		1			FTG BRK MANF-AIR	
R	F6HT-2535-HA		1			FTG BRK MANF-AIR	
R	F6HT-2535-ACA		1			FTG BRK MANF-AIR	
R	F6HT-2535-ACAA		1			FTG BRK MANF-AIR	
R	F6HT-2535-AEA		1			FTG BRK MANF-AIR	
R	F6HT-2535-AHA		1			FTG BRK MANF-AIR	
R	F6HT-2535-AJA		1			FTG BRK MANF-AIR	
R	F6HT-2535-AKA		2			FTG BRK MANF-AIR	
R	F6HT-2535-AMA		1			FTG BRK MANF-AIR	
R	F6HT-2535-ARA		1			FTG BRK MANF-AIR	
R	F6HT-2535-AZA		2			FTG BRK MANF-AIR	
R	F6HT-2535-SA		10			FTG BRK MANF-AIR	
R	F6HT-2535-BA		7			FTG BRK MANF-AIR	
R	F6HT-2535-CA		1			FTG BRK MANF-AIR	
R	F6HT-2535-FA		8			FTG BRK MANF-AIR	
R	F6HT-2535-GA		8			FTG BRK MANF-AIR	
R	F6HT-2535-ANA		1			FTG BRK MANF-AIR	
R	F3HT-2875-FC		1			COMP ASY (BX TU FLO-550 1	
R	F6HT-2875-ACNRA		1			FBR - AIR BRAKE COMPRESSO	
R	F8HT-2885-AA		1			GOVERNOR ASY COMPR	
R	F7HT-2902-BA		1			BRKT-COMP SUPT	
R	F0HT-2917-BMA		1			TUBE ASY - COMP DISCHARGE	
R	F5HT-3010-HA		1			AX - FRT	
R	F6HT-3020-BB		2			BMPR ASY-FRT AX	
R	F7HT-3105-CA		1			SPDL ASY-FRT WHL-RH	
R	F7HT-3106-CA		1			KIT-FRONT SPINDLE ASY LH	
R	D3HA-3113-BA		4	D5HZ-3113-A		CAP-SPDL PIN	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	D3HA-3114-BA		4	C5TZ-3114-A		GSKT-SPINDLE PIN CAP	
R	D5HA-3115-AA		2			PIN-SPINDLE	
R	D5HA-3122-CA		2	D5HZ-3122-B		PIN-SPDL BLT LKG-LWR	
R	D5HA-3122-DA		2	D5HZ-3122-A		PIN-SPDL BLT LKG-UPR	
R	D1HA-3123-CA		2	D2HZ-3123-C		BEARING ASSY-SPINDLE PIN	
R	D3HA-3125-BA		4			SE-SPDL PIN DST	
R	F1HT-3130-JB		1	F1HZ-3130-B		ARM - STEERING SPINDLE -	
R	F1HT-3131-JB		1	F1HZ-3131-B		ARM - STEERING SPINDLE -	
R	F2HT-3138-AA		3			KEY-STNG SPDL ARM	
R	F6HT-3146-JA		1			ARM - STRNG SPINDLE DRAG	
R	F6HT-3280-AA		1			ROD ASY-STNG SPINDLE ARM	
R	F7HT-3294-CA		2			NUT ASY-WHL BRG ADJ F/A	
R	F8HT-3294-AA		4			NUT ASY-WHL BRG ADJ R/A	
R	F6HT-3304-DA		1			LINK ASY - STEERING DRAG	
R	F6HT-3304-CA		1			LINK ASY - STEERING DRAG	
R	ESBM-33J3-A2EQAA		2			ENAMEL-CLEARCOAT-EXTERIOR	
R	F7HT-3490-AE		1			BRACKET - P/S RESERVOIR	
R	F6HT-3530-BE		1			SHROUD-STNG COL UPPER-TIL	
R	F6HT-3530-CC		1			SHRD-STNG COL LOWER BACK	
R	F6HT-3530-GC		1			SHROUD-STNG COL LWR/FRT T	
R	F6HT-3530-AE		1			SHROUD-STNG COL UPPER-TIL	
R	F7HT-3531-BA		1			RESERVOIR ASY - PWR STNG	
R	F6HT-3590-LA		1			ARM-STNG GR PTMN	
R	F6HT-3590-MA		1			ARM-STNG GR PTMN	
R	F7HT-3600-AA		1			WHL ASY STNG-18"	
R	F8HT-3691-AA		1			HOSE-P/S RESERVIOR TO PUM	
R	F6HT-4141-RSTDA		1			FBR - AXLE CARRIER	
R	F6HT-4209-R538A		1			FBR - GEAR SET	
R	F8HT-4310-RASC6TA		1			FBR - AXLE CARRIER	
R	F7HT-4484-AA		1			VALVE ASY - I/S O/S AIR	
R	F7HT-4484-DA		1			VALVE ASY - I/S O/S AIR	
R	F7HT-4484-EA		1			VALVE ASY - I/S O/S AIR	
R	B9TT-4487-A		1			BRACKET	
R	C1TT-4487-A		1			BRACKET	
R	F6HT-4497-RCDCCLBA		1			FBR - AXLE MAIN DIFF	
R	F6HT-4568-CA		1			REINFORCEMENT-RR RR AX TO	
R	D7HT-4568-DA		2			REINF RR AX TOR ARM BRKT	
R	F6HT-4568-BB		1			REINFORCEMENT-FR RR AX TO	
D	E7HT-4602-FZA		1			DRV/SHT ASY-1710 JT	DL: J05
R	F7HT-4730-AA		4			BUMPER ASY-REAR AXLE--END	
D	E7HT-4817-HAA		1			CPL/SHFT ASY-1710 JT	DL: J03
D	F6HT-4831-BA		1			PLT-CPL/SHFT SUPT	DL: 012J01
R	F6HT-4851-RB71BTA		1			FBR - AXLE YOKE	
R	F7HT-4962-BA		1			ARM ASY-RR AX 19.66	
R	F7HT-4962-CA		1			ROD ASY-TRANVERSE 20.62LT	
R	D3HS-4962-MA		1	D7HZ-4612-G		ROD ASSEMBLY - TORQUE (21	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	E3HT-4962-KA		1	E3HZ-4612-D		ROD ASSEMBLY - TORQUE (20	
R	F4HT-4964-ACA		1	F4HZ-4964-A		DRIVE SHAFT ASY-RR AXLE	
R	F8HT-5000-XREGR000		1			SPEC-FRAME ASY	
D	F8HS-5000-XDECF002		1				43QM000006
D	F8HS-5000-XDFUT016		1				43QM000006
R	F8HT-5000-GRBAR026		1			SPEC-FRAME ASY	
R	F8HT-5000-GRDFL005		1			SPEC-FRAME ASY	
R	F8HT-5000-GRECR027		1			SPEC-FRAME ASY	
R	F8HT-5000-GRRSP001		1			SPEC-FRAME ASY	
R	F8HT-5000-XRACC000		1			SPEC-FRAME ASY	
D	F8HT-5000-XRBAF002		1			SPEC-FRAME ASY	43QM000006
R	F7HT-5000-GRTAL038		1			SPEC-FRAME ASY	
R	F8HT-5000-XRCMT001		1			SPEC-FRAME ASY	
R	F8HT-5000-XREGS000		1			SPEC-FRAME ASY	
R	F8HT-5000-XRFBB000		1			SPEC-FRAME ASY	
R	F8HT-5000-XRFSP003		1			SPEC-FRAME ASY	
R	F8HT-5000-XRMAC003		1			SPEC-FRAME ASY	
R	F8HT-5000-XRPST001		1			SPEC-FRAME ASY	
R	F8HT-5000-XRRSC002		1			SPEC-FRAME ASY	
R	F8HT-5000-XRSTR002		1			SPEC-FRAME ASY	
R	F8HT-5000-XRTHF000		1			SPEC-FRAME ASY	
R	F8HT-5000-XRVPH002		1			SPEC-FRAME ASY	
R	F8HT-5000-XRCMI001		1			SPEC-FRAME ASY	
R	F6HT-5000-XRECM146		1			SPEC-FRAME ASY	
R	F6HT-5000-GRCMS023		1			SPEC-FRAME ASY	
R	F7HT-5000-GRCMR005		1			SPEC-FRAME ASY	
D	F6HT-5000-XRATF000		1			SPEC-FRAME ASY	43QM000006
R	F6HT-5000-XRATM036		1			SPEC-FRAME ASY	
R	F6HT-5000-XRBAM092		1			SPEC-FRAME ASY	
R	F6HT-5000-XRBBX021		1			SPEC-FRAME ASY	
R	F6HT-5000-XRBCC065		1			SPEC-FRAME ASY	
R	F6HT-5000-XRCLC000		1			SPEC-FRAME ASY	
R	F6HT-5000-XRCMB000		1			SPEC-FRAME ASY	
R	F6HT-5000-XREOF000		1			SPEC-FRAME ASY	
R	F6HT-5000-XREXH001		1			SPEC-FRAME ASY	
R	F6HT-5000-XRFMF000		1			SPEC-FRAME ASY	
R	F6HT-5000-XRFRR000		1			SPEC-FRAME ASY	
R	F6HT-5000-XRFTS001		1			SPEC-FRAME ASY	
R	F6HT-5000-XRFUL026		1			SPEC-FRAME ASY	
R	F6HT-5000-XRMAC000		1			SPEC-FRAME ASY	
R	F6HT-5000-XRMAC004		1			SPEC-FRAME ASY	
R	F6HT-5000-XRWWR000		1			SPEC-FRAME ASY	
R	F8HT-5000-XRFSA000		1			SPEC-FRAME ASY	
R	F8HT-5015-DAMEA		1			SIDEMEMBER-FRAME-RH	
R	F8HT-5016-DAMEA		1			SIDEMEMBER-FRAME-LH	
R	F8HT-5024-AB		1			C/M ASY RAD SUPPORT	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F6HT-5025-AB		1			CROSSMEMBER ASSY-FRAME #2	
R	F8HT-5027-AA		2			CROSSMEMBER ASY - FRAME #	
R	F8HT-5036-AA		1			CROSSMEMBER ASY - FRAME #	
R	F8HT-5036-GA		1			C/M ASY-FR #5	
R	F8HT-5086-AA		1			BRACKET-ENG SUPT TO FRAME	
R	F8HT-5087-AA		1			BRKT-ENG SUPT LH	
R	F6HT-5246-AA		1			PIPE ASY - MFLR INLET	
R	F7HT-5255-AFA		1			PIPE MUFFLER-INLET	
R	F6HT-5263-GA		1			EXT-MFLR OLET PIP	
R	F6HT-5291-GA		1			BRKT-MFLR INLET PIPE	
R	F6HT-5310-AAA		2			SPRG ASY -54",ML,7200#	
R	F6HT-5335-CA		2			BRKT ASY-FRT SUSP SHKL RH	
R	F8HT-5340-AA		1			BRKT-FRT SPG RH	
R	F8HT-5341-AA		1			BRKT-FRT SPG LH	
R	D7HT-5455-DA		4	DOHZ-5455-G		U-BOLT FRT SPG	
R	F4HT-5458-AA		2			SPCR-FRT SPG PLT	
R	F6HT-5580-BD		4			SPRNG ASY-RR SUSP AIR	
R	D7HA-5883-BA		2	D8HZ-5883-A		BRKT-RR AX TOR ARM TO FR	
R	D7HT-5883-DA		2	D8HZ-5883-B		BRKT-RR AX TOR ARM TO FR	
R	F6HT-6012-AC275AB		1			FBR-ENG ASY FD1460 275 HP	
R	F6HT-6028-BB		1			BRKT ASY-ENG FRT SUPT	
R	F6HT-6038-DB		1			INSULATOR ASY - ENG FRT S	
R	F6HT-6039-CA		1			INSULATOR ASY - FRT SUPT	
R	F6HT-6068-AB		2			INSUL ASY-ENG RR SUPT-RH	
R	F6HT-6096-BA		1			BRACKET - ENG SUPT RR RH	
R	F5HT-6132-AA		8			SPACER-CYLINDER FRONT COV	
R	F7HT-6346-AA		1			DECAL - ENGINE STARTING I	
R	F6HT-6392-ACSAAA		1			FBR - ENGINE FLYWHEEL GRO	
R	E3HN-6438-AB		1	E6HZ-6438-A		COVER-FL/WHL ACCESS	
R	F8HT-6974-KA		1			MANUAL-ENG OPER INST (ENG	
R	F7HT-7003-FAEA		1			FBR-TRANS & EXT ASY RTO-1	
R	F6HT-7017-FH175A		1			FBR-SHAFT-TRANS INPUT	
R	48ZF-7057-		1			OWNERS MANUAL PALSTIC BAG	
R	F7HT-7089-FA1710A		1			FBR-YOKE-U JT SPLINE-ENG	
R	F6HT-7210-MA		1			LEVER - TRANS CONTROL SEL	
R	F8HT-7213-BA		1			BL ASY-TRANS GR SH LVR	
R	F3HT-7502-GA		1			CL ASY	
R	F6HT-7505-FAA2A		1			FBR-HOUSING CLUTCH	
R	F7HT-7510-AB		1			SHAFT - CLUTCH RELEASE	
R	F7HT-7511-DB		1			LEVER-CLUTCH RELEASE SHAF	
R	F6HT-7519-AA		1			PDL ASY-CL	
R	D0HA-7523-Y		1			SPG-CL REL RETR	
R	F8HT-7530-DA		1			ROD ASY-CL REL	
R	C3TS-7541-A		1	C6TZ-7515-A		LVR-CLUTCH RELEASE	
R	F6HT-7542-EA		1			BRACKET - CLUTCH RETURN S	
R	F7HT-7562-BA		1			SPRING-CL REL LVR/ANTI-RA	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	C1TT-7590-A		1	C1TT-7590-A		SHFT-CL REL STUD	
R	F2HT-7600-AA		1	F2HZ-7600-B		BEARING ASY TRANS INPUT P	
R	F6HT-7961-FB17MA		1			FBR - SHFT TWR - MED TWR	
R	48ZF-7968-		1			CARPET PROTECTOR-RH	
R	48ZF-7969-		1			CARPET PROTECTOR-LH	
R	CSE-7972-TX198		1			WARRANTY INFORMATION BOOK	
R	F8HT-8009-VA		1			RAD & SUPT ASY	
R	E8HT-8100-BA		1	E6HZ-8100-D		CAP ASSY RAD	
R	F6HT-8146-EC		1			SHROUD-FAN	
R	F7HT-8150-AB		1			RAD GRILLE	
R	F7HT-8198-BB		1			SCRN ASY-RAD BUG (W/O PTO	
R	F7HT-8286-KA		1			HOSE - RADIATOR LOWER	
R	F7HT-8286-EA		1			HOSE - RADIATOR LOWER	
R	E9HS-8287-CA		8			SPEC-RADIATOR HOSE CLAMP	
R	E9HS-8287-BA		1			SPEC-RADIATOR HOSE CLAMP	
R	E8HS-8287-AA		3			SPEC-RADIATOR HOSE CLAMP	
R	E7HS-8287-CA		4			SPEC-RADIATOR HOSE CLAMP	
R	F8HT-8291-DA		1			PIPE ASY-RADIATOR LOWER	
R	F7HT-8419-BA		1			SPEC-MLDG RAD GRL UPR	
R	F3HT-8600-CA		1	F3HZ-8600-A		FAN ASY-ENG COOLING	
R	F6HT-8620-ASA		1			BELT DRIVE-A/C TO FAN 46.	
R	F6HT-8620-AYA		1			BELT DRIVE	
R	F6HT-8625-AA		1			BRKT & PLY ASY-FAN	
D	F7HT-9002-CAA		1			TNK ASY-FUL	43QM000006
D	F7HT-9002-CBA		1			TNK ASY-FUL	43QM000006
D	F6HT-9046-AB		4			BRACKET - FUEL TANK SUPPO	43QM000006
D	F6HT-9054-AD		4			STRP ASY-FUEL TANK	43QM000006
R	D3HA-9067-BA		2			INSULATOR-FU/TNK STRAP	
R	F6HT-9067-BA		2			INSULATOR-FUEL TANK	
D	F3HS-9189-BA		1	F4HZ-9189-B		VLV ASSY-FUEL TANK	44HW000013
R	F6HT-9275-DB		1			SDR ASY - FUEL TANK	
R	C1TF-9276-C		1	C1TF-9276-C		GSKT-FU LEVEL SENDER	
R	F6HT-9278-BB		2			SW ASY - OIL PRESS SNDR	
R	F5HT-9285-AA		1			VALVE ASSY CHECK	
R	C3TA-9338-C		2	C3TA-9338-C		BRKT	
R	C3TA-9338-F		1			BRKT.	
R	F6HT-9600-AC		1			CLNR ASY ENG AIR	
R	F6HT-9735-AC		1			PEDAL ASY-ACCELERATOR	
R	F4HT-9737-AA		1	F4HZ-9737-A		SPG-ACEL SHFT RET	
R	8BA-9792-		1	8BA-9792-		CLAMP-CARB CHOCK BRKT	
R	F6HT-9798-AB		1			ARM - ACCEL PDL	
R	TOTAL-PROD-HEAVY		1			TOTAL KTP MED/HVY PRODUCT	
R	F5HT-10270-BA		1			STRAP - ALT SUPPORT	
R	F4HT-10300-KA		1			ALTERNATOR ASSY	
R	F6HT-10655-DA		2			BATTERY ASSY	
R	F6HT-10708-AA		1			BRACKET-BATT CVR CLAMP	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F6HT-10718-AA		1			CLAMP-BATTERY HOLD DOWN	
R	F7HT-10732-BA		1			SUPPORT ASY - BATTERY	
R	F6HT-10753-AB		1			BRACKET-BATTERY SUPPORT	
R	F6HT-10753-MB		1			BRACKET-BATTERY SUPPORT	
R	F6HT-10753-BB		1			BRACKET-BATTERY SUPPORT	
R	F6HT-10753-LB		1			BRACKET-BATTERY SUPPORT	
R	F6HT-10756-BB		2			BOLT - BATTERY CLAMP	
R	F7HS-10849-YA		1			CLUST ASY - INST	
R	F3HT-10884-AA		1	F3HZ-10884-A		SENDER ASY-WATER TEMP IND	
R	F6HT-11001-CB		1			MOTOR ASY-STARTER	
R	F5TU-11450-BA		1			RELAY ASY-STR MTR	
R	D8TB-11572-AA		1	D8TZ-11572-A		SWITCH ASY-IGNITION	
R	C9AB-11584-B		1	C9AZ-11584-A		BEZEL IGNITION SWITCH	
R	F2DB-11654-AA		1	F2DZ-11654-A		SWITCH ASY LT	
R	F2DB-11666-ABJABF		1	F2DZ-11666-A		KNB ASY-LT SW	
R	F2UB-13007-AA		2	F3UZ-13007-A		BLB ASY HD/LP	
R	E69B-13018-AA		2	E69Z-13015-A		RG HD/LP BLB RET	
R	D5UB-13031-AA		2	D5UZ-13031-A		SPG HD/LMP RING	
R	E99B-13037-AA		1	E99Z-13118-A		RING HD/LP ADJ	
R	E99B-13047-AA		1	E99Z-13119-A		RING HD/LP ADJ	
R	F5HB-13200-BC		1	F5HZ-13200-D		LP ASY-PRK LP RH	
R	F5HB-13201-BC		1			LP ASY-PRK LP LH	
R	F4HT-13404-BB		1			LENS ASY RR RH	
R	F4HT-13405-BB		1			LENS ASY RR LH	
R	D7HA-13406-AA		1	D8HZ-13406-A		BRKT RR LIC	
R	F5TB-13470-BA		2			BRKT RR LP RH	
R	F6HT-13480-AB		2			SW ASY-STP LP	
R	F6HT-13706-ABZUKE		1			LAMP ASSY - COURTESY LAMP	
R	F6HT-13707-ABZUKE		1			LAMP ASSY - COURTESY LAMP	
R	E8DB-13713-AA		2	E8DZ-13713-A		SW ASY-CURT LP	
R	F7HT-13740-AB		1			SW ASY INST PNL LP	
R	F7HT-13776-AA		1			LAMP ASSEMBLY - INTERIOR	
R	E9SB-13783-AA		1	E9SZ-13783-A		LENS-INTR	
R	F6HT-13802-AA		1			HORN & BRKT ASY-LOW PITCH	
R	F8HT-13910-AA		1			VLV ASY-HORN AIR CONTR	
R	E7HT-13932-AA		2	E7HZ-13932-A		PAD-HORN MNTG BRKT	
R	E7HT-13932-BA		2	E7HZ-13932-C		PAD-HORN MNTG BRKT	
R	E7HT-13933-CA		2	E7HZ-13933-C		PLATE-HORN MTG REINF	
R	F7HT-14289-LGBC50		1			FBR - ALL TRANS EXCEPT EL	
R	F8HT-14289-LBB		1			WIRING ASY-DASH EN GAGE F	
R	F8HT-14289-LBBC11		1			FBR - FD 1460 DIESEL ENGI	
R	F7HT-14289-LGBC65		1			FBR - AL TRNS LS FL MT EL	
R	F8HT-14289-LBAV40		1			FBR - (MAN TRANS*FLY PTO)	
R	F7HT-14289-LGEJ09		1			FBR - ENGINE AIR INTAKE H	
R	F7HT-14289-LGCK57		1			FBR - ENG WRN CHIME W OR	
R	F7HT-14289-LGBH03		1			FBR - AIR COND	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F7HT-14289-LGAM24		1			FBR - ELECT AUTO TRANS PE	
R	F7HT-14289-LGBS19		1			FBR - ALL RAD OR RAD PREP	
R	F7HT-14289-LGAK93		1			FBR - ENG WRN W OR W/O SH	
R	F7HT-14289-LGAC49		1			FBR - MAN TRNS/EL AUT TRN	
R	F7HT-14289-LGAC17		1			FBR - ALL MANUAL TRANSMIS	
R	F7HT-14289-LGAB01		1			FBR - ALTERNATOR DELCO	
R	F7HT-14289-LGAU43		1			FBR-MOT ALT/ALL TRANS = F	
R	F6HT-14290-LADL20		1			FBR-ABS / FUEL S-O(ING) /	
R	F8HT-14290-LBD000		1			FBR - BASE	
R	F8HT-14290-LBAK97		1			FBR - ALL LEFT HAND FUEL	
R	F8HT-14290-LBAK57		1			FBR - ENG WRN CHIME W OR	
R	F8HT-14290-LBAJ19		1			FBR - HTD AIR INTAKE OR C	
R	F7HT-14290-LUAA01		1			FBR - FUSES	
R	F7HT-14290-LBAM24		1			FBR - J CAB 111" BBC	
R	F6HT-14290-LLAM11		1			FBR-CUST ACC RR CHAS/RR O	
R	F6HT-14290-LLAM10		1			FBR - CUST ACC RR CHAS /	
R	F8HT-14290-LBE		1			WIRING ASY - DASH PNL TO	
R	F6HT-14290-LADS21		1			FBR - RADIO CB HOT POST	
D	F4HT-14300-DAA112		1	F4HZ-14300-CN		CABLE ASSY - BATT TO STR	BATT CABLOO
D	F7HT-14301-DEB120		1			CABLE ASY - BATTERY NEG	BATT CABLOO
R	F8HT-14334-LBA		1			WIRING ASY - INTERIOR LAM	
R	F7HT-14400-BA		1			WIRING DIAGRAM	
R	F8HT-14401-LBAM04		1			FBR - CUST ACCESS RR CHAS	
R	F8HT-14401-LBAC07		1			FBR - FUEL SHUTOFF AND ME	
R	F8HT-14401-LBAC17		1			FBR - MANUAL TRANS	
R	F8HT-14401-LBAC65		1			FBR-ALL TRNS LS FLR MTD E	
R	F8HT-14401-LBAC90		1			FBR - DDC/EL AUTO TRANS/A	
R	F8HT-14401-LBAE40		1			FBR - LESS DRL/(USA W/DRL	
R	F8HT-14401-LBAE48		1			FBR - T/S SWITCH SIG STAT	
R	F8HT-14401-LBAH03		1			FBR - AIR CONDITIONING	
R	F8HT-14401-LBAJ19		1			FBR - WIR HTD AIR INTAKE	
R	F8HT-14401-LBAK09		1			FBR - WIR ELEC INSTR CLUS	
R	F8HT-14401-LBAK57		1			FBR - ENG WARN CHIME W /	
R	F8HT-14401-LBAM02		1			FBR - CUST ACCESS ENG COM	
R	F8HT-14401-LBE000		1			FBR - BASE	
R	F8HT-14401-LBAM16		1			FBR-CUST ACC RR CHAS/RR C	
R	F8HT-14401-LBAS18		1			FBR - WEATHERBAND RADIO	
R	F8HT-14401-LBAU39		1			FBR - HTD AIR INT/3306/CU	
R	F8HT-14401-LBAU43		1			FBR-MOTO ALT/TRNS LS FLR	
R	F8HT-14401-LBAV70		1			FBR - MECHANICAL ENGINES	
R	F8HT-14401-LBAV71		1			FBR - W/O ALLIS EL A/T I/	
R	F8HT-14401-LBBC50		1			FBR - ALL TRANS EXCEPT EL	
R	F8HT-14401-LBBU31		1			FBR- LS SPEED CTRL*(LS PT	
R	F6HT-14401-LABD05		1			FBR-LK DIFF/SUS DMP/5 SL/	
R	F8HT-14401-LBAA01		1			FBR - FUSES	
R	F8HT-14401-LBE		1			WIRING ASY - MAIN	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F8HT-14401-LBAM01		1			FBR - CUSTOMER ACCESS BAC	
R	F6HT-14401-LABS29		1			FBR - ALL RADIOS(INCL PRE	
R	F6HT-14401-LABS13		1			FBR-ALL RADIOS LESS CELLU	
R	F7HT-14401-LBAK99		1			FBR-EL ENG/ENG WRN CHM W/	
R	F6HT-14401-LAAD10		1			FBR - SUSP DUMP/5TH WHL S	
R	F6HT-14401-LABC84		1			FBR - ALL MIDRANGE ENG	
R	F6HT-14401-LABM15		1			FBR-WIR CUST ACC WITH SIG	
R	F6HT-14401-LABS22		1			FBR-RAD CB HOT PST HDR CN	
R	F6HT-14401-LABT26		1			FBR - ALL SLEEPERS OR RAD	
R	F6HT-14401-LABU40		1			FBR-WIR DDC/HTD AIR INT/3	
R	F6HT-14401-LACD04		1			FBR - WHEEL TO WHEEL DIFF	
R	F6HT-14401-LACL20		1			FBR-WIR ABS OR FUEL SHT O	
R	F7HT-14401-LAAL39		1			FBR-AC/EX BK/3306+EN BK/E	
R	F7HT-14401-LBAC93		1			FBR-EL ENG/ENG WRN CHM W/	
R	F7HT-14401-LABK97		1			FBR - ALL LH FUEL TANKS	
R	F6HT-14401-LABS16		1			FBR - MESSAGE CENTER/ALL	
R	F7HT-14401-LAAT10		1			FBR - WIR TRUCK ONLY CIRC	
R	F6HT-14401-LACM10		1			FBR-WIR CUST ACC RR CHAS	
R	F6HT-14401-LMBS09		1			FBR - ALL RADIOS OR RADIO	
R	F6HT-14401-LAFS08		1			FBR - HEADER CONSOLE-CB H	
R	F6HT-14401-LADS27		1			FBR-WIR RH CNTL PNL AIR V	
R	F6HT-14401-LACS21		1			FBR - RADIO CP HOT POST	
R	F6HT-14401-LACM11		1			FBR-WIR CUST ACC RR CHAS/	
R	F8HT-14405-LAF		1			WIRING ASY - REAR LAMP	
R	F8HT-14405-LAAM11		1			FBR-CUST ACC RR CHAS/RR O	
R	F7HT-14405-LADAH03		1			FBR - AIR COND	
R	F8HT-14405-LACM01		1			FBR - CUSTOMER ACCESS BAC	
R	F8HT-14405-LACE21		1			FBR-TL LMPS T/A TRUK*(TRK	
R	F8HT-14405-LACD12		1			FBR - WHL TO WHL TANDEM A	
R	F8HT-14405-LAB000		1			FBR - BASE	
R	F8HT-14405-LAAM33		1			FBR - NEWAY 54" REAR SUSP	
R	F8HT-14405-LAAM24		1			FBR - J CAB 111" BBC	
R	F8HT-14405-LACM04		1			FBR - CUST ACCESS RR CHAS	
R	F8HT-14405-LAAM02		1			FBR - CUST ACCESS ENGINE	
R	F8HT-14405-LAAH10		1			FBR - A/C W/VISCOUS FAN C	
R	F8HT-14405-LAAE86		1			FBR - 214" WHEELBASE	
R	F8HT-14405-LAAE58		1			FBR - TANDEM AXLE	
R	F7HT-14405-LAUAM13		1			FBR - CUST ACC RR CHASSIS	
R	F7HT-14405-LAUAD04		1			FBR - WHEEL TO WHEEL DIFF	
R	F8HT-14405-LAAM10		1			FBR - CUST ACC RR CAS / R	
R	F7HT-14407-LAAK97		1			FBR - ALL LEFT HAND FUEL	
R	F7HT-14407-LAAM24		1			FBR - J CAB 111" BBC	
R	F7HT-14407-LAAM31		1			FBR-LH/DU -2 FWD MT/-3,5	
R	F7HT-14407-LAB		1			W/A - LH FUEL TANK/AIR DR	
R	F6HT-14603-GA		1			SPEC GROMMET WRNG	
R	F6HT-14603-AC		2			SPEC GROMMET WRNG	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F6HT-14630-LAE000		1			FBR - BASE	
R	F8HT-14630-LAA		1			FBR - W/A WINDOW REG RIGH	
R	F6HT-14631-LAD000		1			FBR - BASE	
R	F8HT-14631-LAA		1			FBR - W/A WDO REG LFT FRT	
R	F8HT-14953-BA		2			BRKT HD HGE LH	
R	F1HT-15052-AA		1	F1HZ-15052-A		KNOB & ELEM ASY CIGAR LTR	
R	F1HT-15055-AA		1	F1HZ-15055-A		SCKT & RET ASY CGR LTR	
R	F6HT-15442-DB		5			CAB MARKER LAMP ASSEMBLY	
R	F6HT-15443-AA		1			SWITCH ASY - MARKER LAMP	
R	F7HT-15520-CB		1			SW ASY-B/UP LP	
R	F6HT-15543-AA		1			SWITCH ASSY (DIAGNOSTIC)	
R	F8HT-16000-GAF		1			HOOD-BASE VOCATIONAL (FBR	
R	F8HT-16005-AB		1			FNDR ASY-FRT RH	
R	F8HT-16006-AB		1			FNDR ASY-FRT LH	
R	F6HT-16700-AE		2			LATCH ASY - HOOD	
R	F7HT-16794-DA		1			BRKT-HOOD SUPT RAD	
R	F8HT-16800-AC		1			HGE ASY-HOD	
R	F8HT-16801-AC		1			HGE ASY HOD	
R	F7HT-16874-AA		2			PLATE - HOOD LATCH	
R	F6HT-17016-BB		1			SUPT ASY - R/V O/S MIR UP	
R	F6HT-17035-AA		1			WRENCH - WHL NUT CVR	
R	F6HT-17059-DB		1			SUPT ASY-R/V O/S MIR LWR	
R	E7HT-17259-DA		1			CVR-SPEEDOMETER /TAPE/	
R	F6HT-17345-HB		1			MAGNET ASY-SPEEDOMETER	
R	C4ZB-17450-C		1	C5ZZ-17531-A		CLIP W/SHLD WPR ARM	
R	F6HU-17504-AD		1			MOTOR ASSY - WINDSHIELD W	
R	F7HT-17526-AA		2			ARM ASY - W/SHIELD WIPER	
R	F6HT-17532-AC		1			ARM & PVT SHFT ASY-W/SHIE	
R	F6DB-17593-AA		2			BLD ASY W/W LS FRAME	
R	F8HT-17752-BA		1			BRKT-FRT BMPR RH	
R	F8HT-17753-CA		1			BRKT-FRT BMPR LH	
R	F8HT-17757-CA		1			BMPR-FRT	
R	F6HT-18045-CC		2			SHK ABS ASY-FRT	
R	F6HT-18080-EA		4			SHK ABS ASY-RR	
R	F1HT-18112-DB		1	F1HZ-18112-C		BRKT ASY-FRT SHK ABS LWR-	
R	F1HT-18113-DB		1	F1HZ-18113-C		BRKT ASY-FRT SHK ABS LWR	
R	F1HT-18183-AA		1	F1HZ-18183-A		BRKT ASY-FRT SHK ABS UPR	
R	F1HT-18184-AA		1	F1HZ-18184-A		BRKT ASY-FRT SHK ABS UPR	
R	C1TT-18197-A		8	C1TT-18197-A		BUSHING-SHK ABS RUBBER IN	
R	F6HH-18478-AC		1			HTR ASY	
R	E9HT-18495-AA		1	FOHZ-18495-A		VALVE ASY - HTR WTR CONTR	
R	F6HT-18663-AAA		1			TUBE ASY HTR WTR INLET	
R	F6HT-18696-TA		1			TUBE ASY-HEATER WATER INL	
R	O9B-18717-		2			COUPLING ASSY	
R	F6HT-18737-AB		2			SWITCH ASY-LOW AIR PRESSU	
R	F6HF-18812-AB		1			CABLE ASY-RADIO ANT LEAD-	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	E0UF-18813-AA		1			KIT-RADIO ANTENNA (3-STEP	
R	F48F-18971-AA		2	F58Z-18808-A		SPKR ASY-RADIO REAR SEAT	
R	F6HT-19710-BA		1			CONDENSER ASY-A/C	
R	F6HT-19835-JB		1			TUB ASY - A/C DEHY TO EVA	
R	F8HT-19835-AB		1			TUBE ASSY - A/C DEHY TO E	
R	F6HT-19867-VA		1			TUBE & HOSE ASY-A/C EVAP	
R	F6HT-19972-JA		1			TUBE ASY-A/C COMPR TO CON	
R	F7HH-19980-AA		1			CONTROL ASY-A/C	
R	F6HT-1A108-BA		2			KIT - WHL ORN & LUG NUT C	
R	F6HT-1K024-BA		48			NUT-WHEEL 2.PC FLANGE	
R	F7HT-2A051-AA		1			BRKT	
R	F8HT-2A095-BA		1			VLV OK REL	
R	F8HT-2A095-AA		6			VLV QUICK RELEASE	
R	F6HT-2A130-AA		1			BRACKET-AIR RESVR TANK SU	
R	F6HT-2A130-BA		1			BRACKET-AIR RESVR TANK SU	
R	E1HT-2A155-LA		2			BRACKET	
R	F8HT-2A155-DA		5			BRACKET-BRAKE TUBE CLIP	
R	F6HT-2A155-NB		2			BRKT-CABLE & TUBE MOUNTIN	
R	F6HT-2A155-AFA		2			BRKT - BRAKE HOSE CLIP	
R	F6HT-2A155-AEA		3			BRKT-CABLE & TUBE MOUNTIN	
R	F5HT-2A155-JA		1			BRKT-CABLE & TUBE MOUNTIN	
R	E9HT-2A155-HA		1			BRACKET - TUBE MOUNTING	
R	E0HT-2A155-KA		1			BRACKET	
R	C7TA-2A155-F		1			BRKT	
R	C3TA-2A155-D		1	C3TA-2A155-D		BRKT	
R	F4HT-2A155-HA		1			BRKT-CABLE & TUBE MOUNTIN	
R	F8HT-2A268-DB		2			BRKT-QUICK REL VLV MTNG	
R	D0HA-2A268-B		1			BRKT QK REL VLV MTNG	
R	F8HT-2A268-BC		2			BRKT-QUICK REL VLV MTNG	
R	F7HT-2A270-AA		1			VLV ASY-BRK FT CNTL	
R	F7HT-2A275-AA		1			BRACKET - BRAKE TUBE SUPP	
R	F8HT-2A289-ASA		1			HOSE ASY-BRK RLV VLV	
R	F8HT-2A289-ATA		1			HOSE ASY-BRK RLV VLV	
R	F8HT-2A289-AYA		2			HOSE ASY-BRK RLV VLV	
R	D0HA-2A292-B		3			CONNECTOR	
R	F2HT-2A292-AA		1	F2HZ-2A292-A		CONNECTOR - 90 DEG ELBOW	
R	C5TA-2A384-A		1	C5TZ-2A384-A		COUPLING ASY-1/4	
R	F6HT-2A435-AA		1			VLV. ASY BRK. AIR. PRESS.	
R	F8HT-2A442-GA		1			HOSE ASY-RR WHL BRK-RH	
R	F8HT-2A442-FA		2			HOSE ASY-RR WHL BRK-RH	
R	F8HT-2A442-DA		1			HOSE ASY-RR WHL BRK-RH	
R	F8HT-2A442-EA		2			HOSE ASY-RR WHL BRK-RH	
R	E6HT-2A449-AA		1	E6HZ-2A449-A		VLV ASY	
R	E5HT-2A550-BA		1	C3TZ-2A550-A		VLV-AIR RESVR SAFETY	
R	F3HT-2A567-AA		4	F3HZ-2A567-A		COCK ASY-BRK RSVR DR	
R	E0HT-2A622-EA		1			VALVE ASSY-PARKING BRAKE	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP

R	E5HT-2A783-BA		1	E1HZ-2A783-A	VALVE ASY-P/BRK RESVR		
R	E4HT-2A848-BA		1	E4HZ-2L781-A	KNOB-P/BRK REL		
R	E0HT-2A864-AA		1		NUT-P/BRK CONTR		
R	C1TT-2A876-A		1		GASKET COMPR GOV		
R	F7HT-2B063-CA		1		BRKT ASY-BRK RESVR MTNG		
R	F7HT-2B063-DA		1		BRKT ASY-BRK RESVR MTNG		
R	E5HT-2B170-BA		2	E5HT-2B170-BA	VLV ASY-BRK RESVR CK		
R	F6HT-2B223-AA		2		CLIP ASY-BRAKE TUBE		
R	F7HT-2B280-BA		1		MANIFOLD - BRAKE TUBE		
R	F6HT-2B280-AA		1		MANIFOLD - AIR BRAKE SUPP		
R	F6HT-2B280-BA		1		MANIFOLD BRK AIR SPLY		
R	F8HT-2B389-KA		1		BRKT ASY-BRK ANTI LOCK MO		
R	F8HT-2B389-JA		1		BRKT ASY-BRK ANTI LOCK MO		
R	F6HT-2B389-RA		1		BRKT ASY-BRAKE ANTI LOCK		
R	F8HT-2B389-BB		1		BRKT ASY-BRK ANTI LOCK MO		
R	D6TA-2B417-AB0280		1		TUB-NYL 1/4 OD GREEN		
R	D0HA-2B417-AF0940		1		TUB-NYL 1/4 OD BLUE BULK		
R	D0HA-2B417-AG1740		1		TUB-NYL 1/4 TAN		
R	D0HA-2B417-AJ0060		1		TUB-NYL 1/4 OD GREEN BULK		
R	F6HT-2B418-AE0900		1		TUB ASY-1/4 O.D. NLY		
R	D5TA-2B418-AE0600		1		TUBE ASY-NYLON 1/4 O.D.		
R	D5TA-2B418-AE0240		1		TUB ASY-1/4 O.D. NLY		
R	D5TA-2B418-AA0500		1		TUB ASY-1/4 O.D. NLY		
R	D5TA-2B418-AE0055		1		TUB ASY-1/4 O.D. NLY		
R	E6HT-2B420-AA		1		TUBE-VENT-NYLON		
R	D6TA-2B421-AC0030		1		TUB ASY 3/8 ORANGE		
R	D6TA-2B421-AC0270		1		TUB ASY 3/8 YELLOW		
R	D6TA-2B421-AC0500		1		TUB ASY 3/8 YELLOW		
R	D6TA-2B421-AD0260		1		TUB ASY 3/8 RED		
R	D5TA-2B422-AE0065		1		TUBE ASSY-NYLON		
R	F6HT-2B422-AE0970		1		TUBE ASSY-NYLON		
R	D5TA-2B422-AE0550		2		TUBE ASSY-NYLON		
R	D5TA-2B422-AE0135		1		TUBE ASSY-NYLON		
R	D5TA-2B422-AE0115		1		TUBE ASSY-NYLON		
R	D5TA-2B422-AE0085		1		TUBE ASSY-NYLON		
R	D5TA-2B422-AE0100		1		TUBE ASSY-NYLON		
R	D6TA-2B423-AB0200		1		BULK TUBE MATL 1/2 GREEN		
R	D6TA-2B423-AD0435		1		TUBE - 1/2 NYLON RED		
R	D6TA-2B423-AD0340		1		TUBE MATL 1/2 NYLON RED		
R	D6TA-2B423-AD0840		1		TUBE - 1/2 NYLON RED		
R	D6TA-2B423-AB0180		1		BULK TUBE MATL 1/2 GREEN		
R	D6TA-2B423-AB0940		1		BULK TUBE MATL		
R	D6TA-2B423-AB0500		1		TUBE 1/2 GREEN		
R	F6HT-2B424-AB0870		1		TUBE ASSY-NYLON 1/2 GREEN		
R	F6HT-2B424-AD0770		1		TUBE ASSY-NYLON 1/2 RED		
R	D6TA-2B427-AB0210		2		BULK TUBE ASY NYLON BLACK		

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	E2HT-2B431-AA		1	E3HZ-2B431-A		MODULATTNG VALVE /R7/	
R	F3HT-2B513-CA		2			KIT-DUST SHIELD	
R	F3HT-2B514-AA		4			KIT - DUST SHIELD	
R	D7HT-2C036-AA0120		1			TUB ASY-OIL PRESS IND	
R	D7HT-2C036-AA0258		1			TUB ASY-OIL PRESS IND	
R	D7HT-2C037-AA0860		1			HOSE ASY	
R	D7HT-2C038-AA0640		1			HOS ASY-FLTR TO ENG	
D	D7HT-2C038-AA0460		1			HOS ASY	44HW000013
D	D7HT-2C038-AA0520		1			HOSE ASY /RETURN/	44HW000013
D	D7HT-2C039-AA0480		1			HOSE ASY	44HW000013
D	D7HT-2C039-AA0460		1			HOSE ASY OIL RTN	44HW000013
R	F7HT-2C091-DC		1			HARNS ASY-CAB AIR PLUMBIN	
R	F7HT-2C091-FA		1			HARNS ASY-CAB AIR PLUMBIN	
R	F7HT-2C091-JA		1			HARNS ASY-CAB AIR PLUMBIN	
R	D8HT-2C110-AB0640		1			BULK TUBE ASY NYLON GREEN	
R	D8HT-2C110-AB0650		1			BULK TUBE ASY NYLON GREEN	
R	F6HT-2K031-AA		3			TUBE ASY BRAKE	
R	F6HT-2K031-BA		1			TUBE ASY BRAKE	
R	D5TA-2K119-AA		1	D5TZ-2K119-A		VALVE ASY-DBL CHK	
D	E4HT-2K572-AA		1	E4HZ-2K572-A		CONN-BRK TUB	44HW000013
R	F7HT-2L222-AA		1			REINF - BRK PDL SUPT BRKT	
R	F3HT-2L334-AB		1			HOSE - BRAKE OIL DRAIN	
R	F4HT-2W896-AA		2	F4HZ-2W896-A		BLOCK-AIR BRK COMPRESSOR	
R	F8HT-3A540-AB		1			CYL ASSY - P/S ASSIST	
R	F1HT-3A674-AA		1	F1HZ-3A674-D		PUMP ASSY-POWER STEERING	
R	F8HT-3A719-GA		1			HOSE ASSY-P/S PRESS LINE	
R	F7HT-3B676-BB		1			COUPLING ASY-STNG GR SHFT	
R	F6HT-3C040-AA		4			RET - SUSP AIR SPG	
R	E7HT-3C510-AA		1			BRACKET	
R	F7HT-3C529-CA		1			COLUMN ASY - STEERING	
R	F7HT-3D677-AA		1			SEAL ASSY-STNG COL OPENIN	
R	F7HT-3D746-AA		1			COOLER ASSY-PWR STNG OIL	
R	F3HT-3E523-DB		1			CLIP-P/S HOSE	
R	F3HT-3E523-EB		1	F3HZ-3E523-L		CLIP-P/S HOSE	
R	F3HT-3E523-AA		1	F3HZ-3E523-A		CLIP-P/S HOSE TO FRAME	
R	F8HT-3E576-AA		1			TUBE ASSY-P/S PRESSURE LI	
R	F7HT-3E599-AA		1			ELBOW ASSY-P/S PUMP INLET	
R	F6HT-3F527-AD		1			LEVER ASSY-STNG COL LOCK	
R	F7HT-3K376-AB		1			RH UPPER BRKT - SHROUD	
R	F4HT-3K506-AA		1	F4HZ-3K506-B		GASKET-PWR STNG PUMP MTNG	
R	F7HT-3K506-AA		1			ADAPTER-PWR STRNG PUMP GA	
R	F6HT-3N132-AA		1			ARM STRNG SPNDL CYL RH	
R	F8HT-3N503-AA		1			GEAR ASSY - POWER STEERIN	
R	F1HT-3R553-BC		1			HS ASY CYL TO TUBE	
R	F8HT-3R553-AA		2			HS ASY CYL TO TUBE	
R	E7HS-4A333-BA		1			KIT-RR AXLE INSTR	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP

R	F6HT-4A489-RLESSA		1			FBR - AXLE- LESS ABS	
R	F6HT-4B401-RDNAATA		1			FBR - AXLE SUSP BRKT.	
R	F6HT-4B430-RT46ECA		1			AX ASY RR RR-RR20145-NFNN	
R	E7HS-4K157-AA		1			DECAL-AXLE DIFF LOCKOUT I	
R	F6HT-5A032-EA		2			GUSSET - FRAME #5	
R	F6HT-5A106-DB		1			BRKT REAR AXLE TO BODY LH	
R	F8HT-5A112-AA		1			BRKT-ASY-FR TO BDY RH	
R	F8HT-5A113-AA		1			BRKT ASY-FR TO BDY LH	
R	C5TA-5A147-A		2			DECAL-FRM WARN	
R	F8HT-5A153-AJA		1			REINF FRAME RH	
R	F8HT-5A154-AJA		1			REINF FRAME L.H.	
R	F6HT-5A204-DB		1			BRACKET - MUFFLER SUPPORT	
R	F6HT-5A204-YB		1			BRACKET - MUFFLER SUPPORT	
R	F6HT-5A235-AC		1			BRKT - MUFFLER OUTLET PIP	
R	F6HT-5A235-DA		1			BRKT - MUFFLER OUTLET PIP	
R	D0HA-5A239-N		1			U BOLT	
R	E0HT-5A272-BA		1			CLMP-MFLR OLET PIP	
R	F6HT-5A273-BA		1			SHIELD ASY - MUFFLER HEAT	
R	F4HT-5A281-DB		1	F4HZ-5A281-B		CLAMP - MUFFLER INLET PIP	
R	B9TT-5A291-A		4	B9TT-5A291-A		SPG MFLR SUPT CLMP	
R	F7HT-5A314-DA		6			PIN FRT SPRING BRKT	
R	F7HT-5A356-DA		2			SUPT-CAB MTNG RR RH	
R	F6HT-5A516-BA		2			BRKT RR-SUSP SUPT BEAM R.	
R	F6HT-5A517-BA		2			BRACKET-RR SUSP SUPT BEAM	
R	F6HT-5A589-AA		2			KIT - RR SUSP SUPPORT BEA	
R	F6HT-5A646-AA		4			ADAPTER ASY SUPT BEAM/BRK	
R	F6HT-5A664-CA		2			ROD ASY-RR SPRNG LVL VLV	
R	F0HT-5A687-BA		1			AIR LVLNG VLV ASY	
R	F4HS-5A687-AA		1	F4HS-5A687-AA		AIR LVLNG VLV ASY	
R	F6HT-5A688-AB		1			BRKT-RIGHT RR SUSP LVL MO	
R	F6HT-5A688-BA		1			BRKT RR SUSP LVL VLV MTG	
R	F6HT-5A743-AA		2			VALVE ASY	
R	F8HT-5B073-EA		2			GUSSET-FRAME SIDE MBR TO	
R	F6HT-5B204-AA		1			CLAMP-MFLR OLET PIP LWR	
R	F6HT-5B260-AC		1			BRACKET - MUFFLER OUTLET	
R	F6HT-5B260-CB		1			BRKT ASY-MFLR OUTLET PIP	
R	F6HT-5B272-AB		1			INSULATOR-ASSY	
R	F6HT-5B286-EB		1			CONN-MFLR INLT PIP FLEX	
R	F6HT-5B286-CB		1			CONN-MFLR INLT PIP FLEX	
R	F6HT-5B286-DB		1			CONN-MFLR INLT PIP FLEX	
R	F6HT-5B311-BB		2			SHACKLE-FRT. SPG.	
R	F7HT-5B362-AA		1			BRACKET - CAB REAR SUPPOR	
R	F7HT-5B363-AA		1			BRACKET - CAB REAR SUPPOR	
R	F8HT-5C107-AA		1			CROSSMEMBER ASY - FRAME R	
R	F7HT-5C229-CB		1			SHLD-MFLR OLET PIP FRT UP	
R	F6HT-5C262-AZA		1			PIP ASY-MFLR OLET	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F7HT-5C264-MA		2			CLAMP - MUFFLER PIPE OUTL	
R	F6HT-5D209-RA		1			EXT MFLR INLT PIP	
R	F6HT-5D252-DB		1			BRACKET-MFLR SUPPORT-UPPE	
R	F6HT-5E220-AA		4			INSULATOR-MUFFLER INLET P	
R	F6HT-5E220-BA		4			INSULATOR-MUFFLER INLET P	
R	F6HT-5F250-FA		1			CONV & PIP ASY-EXH DU/USE	
R	F8HT-5K371-AA		2			INSULATOR-CAB MTG FRT	
R	E6HS-5K678-AA		2			ALIGNMENT BLOCK BUSHING	
R	E6HS-5K678-BA		2			ALIGNMENT BLOCK BUSHING	
R	F7HT-5L039-AA		2			BRKT-FRM TO BDY INS. R.H.	
R	F6HT-6A057-BA		1			SUPT-ENG FRT	
R	F6HT-6A057-ACNRAA		1			FBR - FRT ENGINE MOUNT/FR	
R	F6HT-6A058-ACBER8A		1			FBR-ENG HTR/STRT AID (HN8	
R	F6HT-6A059-AA		2			SPACER -ENG. FRT MNTG BRK	
R	F8HT-6A065-AA		2			CAP ENG SUPT	
R	F6HT-6A070-BA		1			BRACKET - ENG SUPPORT RR	
R	C3TA-6A662-F		1			BRACKET	
R	F6HT-6B008-DC		1			SUPT-ENG FRT-SUPT BRKT /R	
R	F6HT-6B009-DC		1			SUPT-ENG FRT-SUPT BRKT /L	
R	F6HT-6B667-BB		1			TUBE & IND ASY-OIL LVL	
R	F6HT-6C640-AA		3			CONN-ENG CHG A/COOLER DUC	
R	F6HT-6C640-BA		1			CONN-ENG CHG A/COOLER DUC	
R	F1HT-6C653-AA		1	F1HZ-6C653-C		SEAL-ENG AIR DCT TO INK M	
R	F6HT-6E601-ACCATA		1			FBR - ADDED EMISSIONS EQU	
R	F7HT-6F093-ACNRA		1			FBR - ENGINE BRAKES FD146	
R	F7HT-6K769-DA		1			DUCT-ENG CHG AIR COOL TO	
R	F6HT-6K770-BD		1			DUCT-ENG CHRGD AIR CLR TO	
R	F3HT-6K786-AA		1	F3HZ-6K786-A		CLAMP-ENG. CHR.G. AIR COOL	
R	F4HT-6K786-AA		4	F4HZ-6K786-B		CLAMP-ENG CHG AIR COOL	
R	F1HT-6K786-BA		1	F1HZ-6K786-C		CLAMP-ENG CHG AIR COOL	
R	F6HT-6K786-AA		3			CLMP-ENG CHR.G. AIR COOLER	
R	F7HT-6K853-BA		1			ADPT-ENG CHG TO CHG AIR C	
R	F3HT-6M004-AA		1	F3HZ-6E055-A		BRKT.ENG.NSE.SHLD.L.H.	
R	F3HT-6M004-BA		1	F3HZ-6E055-B		BRKT.ENG.NSE.SHLD.L.H.	
R	F7HT-6N602-ACLSFAA		1			FBR - ENG FILTER GROUP FD	
R	F3HT-6P013-AB		1	F3HZ-6775-E		INSL ASY-ENG NOISE SHLD	
R	F6HT-6W023-ACZ07A		1			FBR - ENGINE MISC OPTIONS	
R	TABAJ-77914-B		2	B7T-7034-B		BREA ASY-AUX TRANS CASE	
R	F6HT-7A103-F00A		1			FBR-PUMP ASY-TRANS OIL	
R	F6HT-7A530-AA		1			BRKT-CL PDL BMPR	
R	F6HT-7A533-AC		1			SEAL ASY-CL PDL ROD	
R	F7HT-7A550-AAA		1			SHFT & LEVER-CL PED	
R	F6HT-7B118-AD		1			BOOT-TRANSMISSION GEAR SH	
R	F7HT-7B292-LA		2			DECAL-TRANS SHIFT INSTRUC	
R	F6HT-7C106-AA		1			SW & WIR ASY-TRANS GR SH	
R	E7HS-7N633-AB		1			BRKT-CL REL BRG LUBE	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	E7HS-7R508-AA		1			COVER-CL HSG	
R	F6HT-8A080-BE		1			TANK ASY - RADIATOR SUPPL	
R	E1HT-8A127-FB		1	E1HZ-8A127-A		SPRING RADIATOR LOWER	
R	F6HT-8A290-AB		1			BRKT RAD SUPT LWR RH	
R	F6HT-8A491-AB		1			BRACE-RAD SUPT TO DASH	
R	F3HT-8A616-BA		1	F3HZ-8A616-B		CLUTCH ASY-FAN	
R	F7HT-8B190-DA		3			MLDG RAD GRL OPG PNL CTR	
R	F7HT-8B190-EA		1			MLDG RAD GRL OPG PNL CTR	
R	F7HT-8B242-AB		1			BRACE RAD SUPT L.H.	
R	F7HT-8B463-BA		4			INSULATOR-RADIATOR SUPT.	
R	F6HT-8B608-EB		1			ADAPTER - FAN SPACER - CL	
R	F6HT-8B624-EC		1			BRKT SUPT FAN PLY	
R	F8HT-8C020-AA		1			PLT ASY RAD GRL NM	
R	F8HT-8C061-FA		1			PIPE ASY - RADIATOR UPR	
R	F6HT-8C066-AA0025		1			HOSE-5/8 1D DBL BRD	
R	F6HT-8C066-AA0110		1			HOSE-5/8 1D DBL BRD	
R	F6HT-8C067-AA0270		1			HOSE	
R	F6HT-8C067-AA0220		1			HOSE	
R	F6HT-8C068-AA0460		1			HOSE-1.00 I.D. X 1.22 O.D	
R	F0HT-8C346-AA		1			DECAL-ENG COOL FLTR SERV	
R	F6HT-8C362-CB		1			HOSE ASSY - ENG VENT	
R	F6HT-8K156-DA		4			SPACER-RAD SUPPORT	
R	F6HT-8K554-AA		1			ADAPTOR-WATER OUTLET CONN	
R	F8KE-8N111-AA		2			CLAMP-RADIATOR HOSE LOWER	
R	E8HT-8W287-JA		1	E9HZ-8W287-E		CLIP RAD HOSE	
R	E5HT-9A095-BA		1	E6HZ-9A095-A		LABEL-FUEL-ENGLISH	
R	F4HT-9A095-AA		2	F4HZ-9A095-C		LABEL FUEL (ENGLISH)	
R	F6HT-9A151-AA		1			BRKT-ENG PRMR FLU RESVR M	
R	E8HT-9A153-AA		1	E8HZ-9A153-A		VLV ASSY-FUEL TNK VNT	
R	F6HT-9A710-AA		1			ROD ASY.ACCEL.	
R	F3HT-9A763-CA		1	F3HZ-9A763-C		BUSHING ACCEL SHAFT	
R	F4HT-9A763-AA		1			BUSHING ACCEL SHAFT	
R	F5HT-9A866-AA		2			BRACKET-THROTTLE CONTRL C	
D	F6HT-9B141-AA		2			STEP ASY FUEL TANK	43QM000006
D	F6HT-9B141-ARA		2			STEP ASY FUEL TANK	43QM000006
R	F6HT-9B232-BB		4			CLIP-FU TNK STEP RET	
R	F6HT-9B232-AB		4			CLIP-FU TNK STEP RET	
R	F6HT-9B278-AA		1			TUBE ASY-OIL PRESS IND	
R	F6HT-9B278-FB		1			TUBE ASY-OIL PRESS IND	
R	F6HT-9B339-AA		1			FITTING - OIL PRESS. SEND	
D	F7HT-9B394-AA		1			BRACKET-FUEL VALVE MOUNTI	44HW000013
R	F6HT-9B636-AA		1			SCREEN - HOOD SIDE AIR CL	
R	F6HT-9B637-AA		1			SCRN-HD SIDE AIR CLNR	
R	F6HT-9B687-AB		1			SEAL-ENG.A/CLNR DUCT	
R	F6HT-9B697-AB		1			TUBE ASY-AIR CLNR TO INTK	
R	F6HT-9B699-AA		1			HOSE-AIR CLNR TO INTK MNF	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F6HT-9C678-AC		1			BRKT-AIR CLEANER INTAKE T	
R	F6HT-9C681-AA		1			HOS A/CLNR TO INTAKE	
R	F8HT-9C934-AA		2			DECAL	
R	E2HT-9K652-CA		1	D9HZ-9K652-C		CLAMP ASY	
R	E2HT-9K652-FA		1	D9HZ-9K652-B		CLAMP ASY	
R	E7HT-9K652-AB		2	E7HZ-9K652-B		CLMP-A/CLNR PIP-4.50 T-BO	
R	F7HT-9L276-AA		1			CONNECTOR - FUEL TUBE	
R	EOHT-9N005-BA		5			SEAL-FU TANK	
R	F5HT-9N127-AA		2			PIN-FU/TNK SUPT	
R	F4HT-9N460-AA		1	F4HZ-9N460-A		DECAL WARNING INSTRUCTION	
R	E4HS-9N622-AA		1	E6HZ-9N622-B		IND ASY ENG A/CLNR RESTC	
R	F6HT-9Y425-AB		1			CONTROL ASY - INTAKE MANF	
R	AA-NOISE-DA		1			CATEGORY / CONFIGURATION	
R	F6HT-020B12-AB		2			SLR CWL TWP INR	
R	F6HT-025A48-AC		2			SEAL-FRONT BODY UPPER	
R	F6HT-025B02-AA		2			SLR-FRT BDY UPR INR PILLA	
R	F7HT-10A687-AA		1			COVER ASY - BATTERY	
R	F7HF-10B843-AA		1			SW ASY-WATER TEMP INDICAT	
R	F7HF-10B921-CA		1			SPEC - SW ASSY-OIL TEMP W	
R	F8HT-10B987-AA		1			PNL ASY - WRNG IND	
R	D9HT-10C336-AB		1	D9HZ-10145-B		ARM ASSY-ALT BLT ADJ	
R	E9HT-10C979-BA		2	FOHZ-10C979-B		CVR.-I/P CONT.SW.OPENING	
R	F5HT-10D968-AB		2	F5HZ-10D968-A		LOW COOLANT SENSOR	
R	F7HT-10D969-LABC93		1			FBR-W/A EL ENG OR (ENG WR	
R	F7HT-10D969-LAAK57		1			FBR-W/A ENG WRN CHIME W/O	
R	F7HT-10D969-LAC000		1			FBR - BASE	
R	F7HT-10D969-LAC		1			W/A - LOW COOLANT LVL WAR	
R	F6HT-10E850-AC		1			CONTR ASY IND WRNG FUNCTI	
R	F1HT-11A111-AA		1	F1HZ-11A111-A		SHIELD-STARTER MOTOR RELA	
R	F6HT-11A596-AA		1			RET ASY IGN SW	
R	F5HT-12A468-AA		1			LVR ASY-GOV CONTROL	
R	F5AF-12A648-AA		1	F5AZ-12A648-A		SENSOR ASY-ENG ELEC CNTRL	
R	F4HT-12B536-AA		1			RELY ASY HDLP DIM	
R	F8HT-13A006-LAD		1			WIRING ASY - HEADLAMP (11	
R	F8HT-13A006-LAB000		1			FBR - BASE	
R	F8HT-13A006-LABE15		1			FBR - HEADLAMPS - RECTANG	
R	D8BB-13A093-AB		4	D8BZ-13032-B		SC & NUT ASY HD/LP ADJ	
R	F3HT-13A506-AA		58			RETAINER-RR LAMP WIRING	
R	F1HT-13A506-AA		4	F1HZ-13A506-A		RETAINER-RR LAMP WIRING	
R	E7HT-13A803-EA		1	E7HZ-13832-A		HORN & SUPT ASY	
R	E7HT-13A803-FA		1	E7HZ-13832-B		HORN & SUPT ASY	
R	F8HT-13A805-AA		1			HORN PAD ASY - (BASE LVL	
R	F6HT-13A821-AB		1			BRUSH ASY - HORN BLW RG	
R	F6HT-13A826-AA		1			BRKT-AIR HORN	
R	F8HT-13B302-BA		1			SWITCH ASY-TURN & EMERG S	
R	F7HT-13K081-LAB		1			FBR-WIR ASY-HD/LP WPE/WSH	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F7HT-13K081-LABK57		1			FBR - ENG WRN CHIME W OR	
R	F7HT-13K081-LAAM24		1			FBR - J CAB 111" BBC	
R	F7HT-13K081-LAB000		1			FBR - BASE	
R	F7HT-13K081-LABC93		1			FBR - EL EN/(EN WR CH W/W	
R	F7HT-13K309-AA		2			HOUSING ASY - SIDE TURN S	
R	F8HT-13N232-AB		2			BRKT-LP MTNG	
R	F7HT-14A003-BA		1			COVER - FUSE PANEL	
R	F7HT-14A003-AA		2			CVR-FUSE PNL	
R	F8HT-14A091-DA		1			DECAL - FS JCT PNL BOX CI	
R	F8HT-14A091-CA		1			DECAL - FS JCT PNL BOX CI	
R	F7HT-14A091-GA		1			DECAL-FUSE&RELAY	
R	F8HT-14A091-BB		1			DECAL - FS JCT PNL BOX CI	
R	F6DB-14A094-AA		1			FS ASY-125 AMP	
R	F6HT-14A094-CA		1			FUSE ASSY - 150 AMP	
R	ESD3AB-14A099-AA0120		1			SPEC-FUSE ASY	
R	ESE7LB-14A099-AA0420		1			SPEC-FUSE ASY	
R	ESE7LB-14A099-AA0120		1			SPEC-FUSE ASY	
R	ESE1EB-14A099-AA0180		1			SPEC-FUSE ASY	
R	ESE1EB-14A099-AA0120		2			SPEC-FUSE ASY	
R	ESE1EB-14A099-AA0100		3			SPEC-FUSE ASY	
R	ESD5VB-14A099-AA0200		1			SPEC-FUSE-ASY	
R	ESD42B-14A099-AA0180		1			SPEC-FUSE ASY	
R	ESD42B-14A099-AA0080		1			SPEC-FUSE ASY	
R	ESD3AB-14A099-AA0045		4			SPEC-FUSE ASY	
R	F6HT-14A099-UA0320		1			SPEC-FUSE ASY	
R	F6HT-14A099-FA		1			SHIELD WIRE-WIRE ASSEMBLY	
R	ESD4SB-14A099-BA0055		1			SHIELD-WIRE	
R	F8HT-14A104-LCB		1			HARNESS ASSEMBLY - INSTRU	
R	D9AB-14A163-JC		2	D9AZ-14A163-J		RET WIR HRNS	
R	XC4T-14A206-AA		1			BRACKET - WIRE CONNECTOR	
R	F6HT-14A206-AB		1			BRKT.-WIR. CONN.	
R	F6HT-14A206-BA		1			BRKT.-WIR. CONN.	
R	F6HT-14A206-MC		1			BRACKET - WIRE CONNECTOR	
R	F7HT-14A206-AA		1			BRKT-WIR CONN	
R	F6HT-14A257-ABZUEN		1			COVER ASY-RELAY & CIRCUIT	
D	F6HT-14A280-NANA		1			CABLE ASY BATT NEGATIVE	BATT CABLOO
D	F6HT-14A280-PANA		1			CABLE ASY BATT POSITIVE	BATT CABLOO
R	E9TU-14A396-AA		2	F2UZ-14A396-A		COVER-RELAY	
R	F8HT-14A411-LBBS42		1			FBR - RH CONTROL PANEL AI	
R	F8HT-14A411-LBCV46		1			FBR - DDC-60/AUR SUSP DUM	
R	F8HT-14A411-LBBK01		1			FBR - AIR SUSPENSION DUMP	
R	F8HT-14A411-LBAKA2		1			FBR - MSG CTR/RH CTRL VLV	
R	F7HT-14A411-LBAD10		1			FBR - SUSP DMP/5TH SLIDE/	
R	F7HT-14A411-LBAD03		1			FBR - INTER AXLE DIFF LOC	
R	F8HT-14A411-LBE		1			WIRING ASSEMBLY - MAIN JU	
R	F7HT-14A411-LBAD04		1			FBR - WHEEL-TO-WHEEL DIFF	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F7HT-14A457-AA		3			CAP - WIRE CONNECTOR SLEE	
R	F6HT-14A624-EA		1			CONNECTOR-SPEAKERS/PWR	
R	F7HT-14N072-AA		1			BRACKET - FUSE BOX MOUNTI	
R	F6HT-14N072-BC		1			BRACKET- SPEED MODULE MOU	
R	F7HT-15A271-AA		1			BRKT - CONTROL MODULE	
R	F6HT-15A432-AA		2			LENS FRONT SIDE LAMP	
R	F8HT-16A023-AA		1			BRA FRT FNDR TO RAD SUPT	
R	F6HT-16A023-BB		1			BRACE - FRONT FENDER	
R	F7HT-16A023-FA		1			BRA FRT FNDR TO RAD SUPT	
R	F8HT-16A024-AA		1			BRA FRT FNDR TO RAD SUPT	
R	F7HT-16A024-FA		1			BRA FRT FNDR TO RAD SUPT	
R	F6HT-16A024-BB		1			BRACE - FRONT FENDER	
R	F6HT-16B668-AC		1			PNL ASY - HOOD SIDE AIR C	
R	F6HT-16B669-AC		1			PNL ASY - HOOD SIDE AIR C	
R	F7HT-16B702-AB		1			BRACKET - HOOD STABILIZER	
R	F7HT-16B703-AB		1			BRACKET - HOOD STABILIZER	
R	F7HT-16B816-EA		1			BRKT-HOOD	
R	F8HT-16B875-AB		2			REINF ASSY.-HOOD HINGE ON	
R	F8HT-16B898-AA		1			CABLE ASSY. - HOOD CHECK	
R	F6HT-16B902-AA		2			RET-HOOD SIDE AIR CLR PNL	
R	D0HB-16B920-A		4			RET-HOOD CHECK CABLE	
R	F7HT-16C096-AA		1			REINF - FRONT FENDER MTG	
R	F7HT-16C097-AA		1			REINF - FRONT FENDER MTG	
R	F7HT-16C190-AB		1			BRACE ASY - FRONT WHEEL H	
R	F6HT-16C191-AF		1			BRACE ASY - FRT WHEEL WHO	
R	F6HT-16C658-AB		2			STABILIZER ASY - HOOD	
R	F7HT-16C700-AA		1			PLATE	
R	F6HT-16C704-AA		1			BRACE-HOOD STAB BRKT.	
R	F6HT-16C705-AA		1			BRACE-HOOD STABILIZER (LH	
R	E5HT-16C728-AA		2	E5HZ-16C728-A		SPG-HOOD CHECK CABLE	
R	F8HT-16E012-AA		1			BRACE ASY-FRT FNDR TO DAS	
R	F8HT-16E013-AA		1			BRACE ASY-FRT FNDR TO DAS	
R	F8HT-16N644-AB		1			HOOD ASSIST HANDLE	
R	F6HT-16N781-AB		2			CATCH HOOD LOCK	
R	F6HT-17A386-AA		1			CONTAINER LICENSE PLATE H	
R	F6HT-17A613-AA		4			CLIP - WASHER HOSE	
R	F6HT-17A732-BB		1			SUPT ASY - R/V O/S MIR UP	
R	F6HT-17A734-BA		1			BRA - R/V O/S MIR SUPT RH	
R	F6HT-17A736-DB		1			SUPT ASY-R/V O/S MIR LWR	
R	F8HT-17A954-AB		1			HOOK-TWNG	
R	F8HT-17A955-AB		1			HOOK-TOW FRNT LH	
R	F8HF-17B384-AA		1			SNS & RET ASY - TACH	
R	F7HT-17B613-AA		1			RESV & MTG ASY - WINDOW W	
R	F6HT-17B717-EA		2			MIR & GD ASY-R/V O/S LS A	
R	F6HT-17C708-BA		1			BRA - R/V O/S MIR SUP LH	
R	F8HT-17D539-AA		1			MODULE ASY - WIPER CONTRO	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F7HT-17D541-BA		1			BRACKET - WINDSHIELD WIPE	
R	F6HT-17K605-BB		1			HOSE ASSY - WINDSHIELD WA	
R	F7HT-17K605-AA		1			HOSE ASSY-W/SHLD WSHR	
R	F6HT-18A004-AC		2			BRKT RR SHOCK ABS	
R	F6HT-18A005-AC		2			BRKT RR SHK ABS	
R	C1TT-18A065-A		8	C1TT-18A065-A		WASHER SHK ABS INS-LWR	
R	D9AF-18A927-BA		1	D9AZ-18A927-A		CAP - RADIO ANTENNA BASE	
R	F7HF-18C874-AA		1			AM/FM/CASS WEATHER BAND A	
R	F6HH-18D277-BD		1			DCT-HTR AIR DSTR FLR	
R	F6HH-18D277-AD		1			DCT-HTR AIR DSTR FLR	
R	E8OH-18K459-AA0190		1			SLV HTR HOS PROTECTOR	
R	E8OH-18K459-AA0230		1			SLV HTR HOS PROTECTOR	
R	F6HT-18K897-BA		1			BRKT-RADIO SPKR MTG CONSO	
R	F7HT-19A028-AA		1			BRKT ASSY-RADIO REC.& I/P	
R	F6HT-19A041-LABS09		1			FBR - ALL RADIOS OR RADIO	
R	F6HT-19A041-LAB		1			FBR - WIR ASY RADO SPKR R	
R	F6HT-19A057-EA		1			BRKT-RADIO SPKR MTG SPKR	
R	F6HF-19A182-AA		1			BASE + GASKET ASSY-RADIO	
R	F8HT-19A268-AB		1			MAN-SAF STD CERT	
R	F8HT-19A321-BA		1			MAN-OWNR VEH OPER (HN80)	
R	F7HT-19A321-NA		1			MAN-OWNR VEH OPER	
R	F7HT-19A347-AA		1			DECAL - FEDERAL NOISE COM	
R	E5HT-19A349-AA		1			LBL.-CHAS. CAB CERT	
R	F4HT-19A491-AA		1			DECAL-VEH INSP	
R	F6HT-19A494-AA		70			MODULAR SPACER	
R	F7HH-19B555-AA		1			EVP & BLW ASY-A/C	
R	F8HT-19C501-ACMFCA		1			FBR-VEH MDL IDENT FD1460	
R	F3AH-19D594-CA		1	F3AZ-19D594-C		SW ASY-A/C PRESS CT/OFF	
R	F6HT-19D624-AA		1			BRKT-A/C COMPR.MTNG.	
R	F7HT-19D626-AA		1			SUPPORT-A/C COMPR.MTNG.	
R	F4HT-19D629-CA		1	F4HZ-19703-F		COMPRESSOR & CLUTCH ASY-A	
R	F6HT-19F533-DC		2			MIRROR ASY DIMINISHING	
R	F0TA-19F534-AA		1			LABEL-INCOMPLETE VEHICLE	
R	F8HT-19G241-AA		1			CRD-MAINT INSTR	
R	F6HT-19N586-AA		1			BRKT ASY-A/COMP MNTG	
R	F8HT-19T200-AA		1			MANUAL-PRE DELIVERY INSPE	
D	ESBM-33J100-AAEGAB		3			ENAMEL, ACRYLIC, HIGH SOL	SP4300000100
R	F6HT-517D10-AB		2			SEALER - DRIP MOLDING	
R	TOTAL-SERIES-HN80		1			TEST PART	
R	TOTAL-SERIES-LT8511		1			TEST USAGE	
R	TOTAL-SERIES-TAND		1			PLANNING	
R	TOTAL-SERIES-1460		1			TEST PART 1460	
R	F77B-1023342-AAJABF		2			HNDL ASY-DR WDO REG	
R	F47B-1060262-AAZUCS		2			COVER - FRT ST SHLDR STRA	
R	F65B-1520472-AA		1			DECAL ASY SAF STD CERT	
R	E7TB-1522614-ABJABM		1			HANDLE DR I/S	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	E7TB-1522615-ABJABM		1			HNDL-DOOR I/S	
R	F6HT-3322050-AA		1			LOCKSET	
R	E7EB-5802354-AAZUD4		2			RET CWL SD TR PNL	
R	E9EB-5821982-AB		2	E9FZ-5822008-A		STRK ASY-DR LAT	
R	F6HT-6351496-AB		1			BRKT-RF INTR LP MNTG	
R	F6HT-6501631-AA		1			PLT-VEH IDENT	
R	F6HT-6703209-AB		4			ROOF SEAL	
R	F4HT-6850980-AAZUD4		28			RETAINER - ROOF HEADLINER	
R	F47B-7821812-AA		1			LAT ASY-FRT DR RH	
R	F47B-7821813-AA		1			LAT ASY-FRT DR LH	
R	F6HT-8001670-AD		1			INSULATOR ASY-DASH (ACCES	
R	F6HT-8002015-AD		1			PANEL - COWL TOP OUTER(W/	
R	F6HT-8002044-AAZUKE		1			PANEL - COWL SIDE - RH	
R	F7HT-8002045-AAZUKE		1			PANEL - COWL SIDE - LH	
R	F8HT-8002048-AB		1			PANEL-FRONT W/H FRONT R.H	
R	F8HT-8002049-AA		1			PANEL-FRONT W/H FRONT L.H	
R	F7HT-8002058-AA		1			EXTNSION - COWL TOP SIDE	
R	F7HT-8002059-AA		1			EXT-CWL TOP SD-LH	
R	F6HT-8002066-AA		2			SEAL - BODY SIDE PANEL	
R	F7HT-8002066-AA		2			SEAL - BODY SIDE PANEL	
R	F6HT-8002228-ABYGAX		1			GRILLE - COWL TOP PANEL	
R	F6HT-8002316-AC		3			RETAINER - COWL TOP GRILL	
R	F6HT-8002824-AB		1			SE CWL TOP PNL TO HOOD	
R	F6HT-8002898-AA		1			BRKT COWL SD PNL LWR (TRI	
R	F6HT-8003100-AA		1			GLASS ASY - WINDSHIELD	
R	F6HT-8003110-AC		1			W/S W/SHLD	
R	F6HT-8003209-AA		2			ADHESIVE - ROOF	
R	F7HT-8003408-MBCSB		1			FBR-PNL ASY W/SHLD HDR (A	
R	F6HT-8003488-MAHOB		1			FBR - MISC FRT HDR (HI TR	
R	F6HT-8003488-MBHOC		1			FBR - MISC FRT HDR (CONSO	
R	F6HT-8003488-MHCSA		1			FBR - MISC FRT HDR (HI TR	
R	F7HT-8003488-MCH0A		1			FBR - MISC FRT HDR (RADIO	
R	F6HT-8004100-BBZUDF		1			VIS ASY I/S RH (SGL - PAS	
R	F6HT-8004101-BAZUDF		1			VISOR ASY INSIDE (SGL - D	
R	F6HT-8004118-BB		1			VISOR ASSY EXT-KIT	
R	F6HT-8004131-AEZUCR		2			CLIP - VISOR ARM	
R	F8HT-8004304-AAZUEN		1			PANEL ASSEMBLY - INSTRUME	
R	F7HT-8004364-AB		1			BRKT ASY I/PNL TO CWL SD-	
R	F7HT-8004365-AB		1			BRKT ASY I/PNL TO CWL SD-	
R	F6HT-8004434-ABJAB0		1			BRKT ASY I/PNL PRK BRAKE	
R	F6HT-8004480-ADZUEN		1			PANEL ASY-INSTRUMENT PANE	
R	F6HT-8004481-ACZUEN		1			PANEL ASY-INSTRUMENT PANE	
R	F7HT-8004810-AAZUEN		1			RECPT ASY - I/PNL ASH	
R	F6HT-8010318-BD		1			ACCESS PLATE - ENGINE	
R	F6HT-8010550-ACJAFQ		1			MAT COVER - ENGINE ACCESS	
R	F7HT-8011000-MACSG		1			FBR-UNDERBODY ASSEMBLY	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F6HT-8011117-MDH0B		1			FBR - MISC UPPER BODY HOL	
R	F6HT-8011117-MFCSB		1			FBR - MISC U/BDY (START A	
R	F6HT-8011117-MLHOA		1			FBR - MISC U/BDY (I/P BRT	
R	F7HT-8011173-AA		1			INSULATOR-SOUND FRNT FLR	
R	F7HT-8012003-AA		1			BRACKET - COWL SIDE TRIM	
R	F7HT-8013000-GCJAFQ		1			MAT ASY.FLR.FRT. (A/PLTE)	
R	F6HT-8013096-AB		1			RET FLR CRPT AT ACCL PDL	
R	F7HT-8013204-AA		1			SPCR DR SCF PLT	
R	F7HT-8013205-AA		1			SPCR DR SCF PLT	
R	F6HT-8013208-ACZUKE		1			PLATE - DOOR SCUFF (RH)	
R	F6HT-8013209-ACZUKE		1			PLATE - DOOR SCUFF (LH)	
R	F7HT-8016884-MAH0A		1			FBR - TRANS/ACCEL U/BDY H	
R	F7HT-8020010-MACSF		1			FBR-BODY SIDE ASSY (W/O S	
R	F7HT-8020011-MACSF		1			FBR-BODY SIDE ASSY (W/O S	
R	F7HT-8020100-AAZUDF		1			MOULDING - DOOR STOWAGE C	
R	F7HT-8020124-CB		1			DOOR ASSY RH	
R	F7HT-8020125-BB		1			DOOR ASSY-LH	
R	F7HT-8020782-AA		2			W/STRP DR OPNG	
R	F6HT-8020996-AAZUDF		1			MLDG-DR TRM UPR FRT-RH	
R	F6HT-8020997-AAZUDF		1			MLDG-DR TRM UPR FRT-LH	
R	F6HT-8021402-AE		1			WIND ASY-DR VENT RH	
R	F6HT-8021403-AE		1			WIND ASY-DR VENT LH	
R	F6HT-8021410-AA		1			GLASS DR WDO TINTED RH	
R	F6HT-8021411-AA		1			GLASS-DR WDO TINTED LH	
R	F6HT-8021434-AC		1			W/STRIP ASY - DR WDO GL -	
R	F6HT-8021435-AC		1			W/STRIP ASY - DR WDO GL-	
R	F6HT-8021452-AB		1			W/STRIP ASY DR WDO GL RH	
R	F6HT-8021453-AB		1			W/STRIP ASY DR WDO GL LH	
R	F6HT-8021458-AB		2			CHANNEL ASSEMBLY-DOOR WIN	
R	F6HT-8021508-AB		1			RNR & RET ASY - DR GL LAT	
R	F6HT-8021509-AB		1			RUN & RET ASY - DR GL LAT	
R	F7HT-8021596-AA		1			RUN ASSEMBLY - DOOR GLASS	
R	F7HT-8021597-AA		1			RUN ASSEMBLY - DOOR GLASS	
R	F6HT-8021660-BA		2			RUN DR VT WDO DIV BAR GL	
R	F6HT-8021818-AD		1			REMOTE CTRL ASSY DR LK RH	
R	F6HT-8021819-AD		1			REMOTE CTRL ASSY DR LK LH	
R	F6HT-8021914-AB		1			LINK ASY-DR LAT R/CONTR R	
R	F6HT-8021915-AB		1			LINK ASY-DR LAT R/CONTR L	
R	F6HT-8022166-AB		1			ROD-ASY LAT CNTRL TO CYL	
R	F6HT-8022167-AB		1			ROD-ASY LAT CNTRL TO CYL	
R	F6HT-8022400-AA		1			HNDL ASSY DR-O/S RH	
R	F6HT-8022401-AA		1			HNDL ASSY-DR O/S LH	
R	F7HT-8022800-AA		2			HINGE ASY - FRONT DOOR UP	
R	F7HT-8022806-AA		2			HINGE ASY - FRONT DOOR LO	
R	F6HT-8023200-AB		1			REGULATOR ASY-FRT DR WDO-	
R	F6HT-8023201-AB		1			REGULATOR ASY-FRT DR WDO-	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
R	F6HT-8023227-AA		2			SEAL DR WDO REG HNDL	
R	F6HT-8023712-AEZUDF		1			PNL-DR TR FINISH RH	
R	F6HT-8023713-ADZUDF		1			PNL-DR TR FINISH LH	
R	F6HT-8023718-AAZUKE		1			PCKT ASY-DR RH	
R	F6HT-8023719-AAZUKE		1			PCKT ASY-DR LH	
R	F7HT-8023942-AB1B31		1			PNL ASY-DR TR - RH	
R	F7HT-8023943-AA1B31		1			PNL ASY-DR TR - LH	
R	F8HT-8024582-AAZUDF		1			CVR ASY-QTR PLR TR PNL RH	
R	F8HT-8024583-AAZUDF		1			CVR ASY QTR PLR TR PNL LH	
R	F7HT-8026690-BAZUCN		2			HNDL DR I/S PL	
R	F7HT-8027748-MCH0A		1			FBR - MISC BDY SD RH (HI	
R	F7HT-8027749-MCH0A		1			FBR - MISC BDY SD LH (HI	
R	F7HT-8027749-MHH0A		1			FBR - MISC BODY SIDE LH (
R	F6HT-8028286-AC		1			BRKT - BACK PANEL STRAINE	
R	F7HT-8028494-AA		2			PATCH - ADHESIVE (LWR COW	
R	F6HT-8028494-FA		4			PATCH - ADHESIVE	
R	F6HT-8028494-DA		2			PATCH - ADHESIVE	
R	F6HT-8028494-AA		6			PATCH - ADHESIVE	
R	F6HT-8028494-BA		2			SEAL-BDY SD CRNR REINF	
R	F6HT-8040300-MBCSE		1			(FBR) PANEL ASY - BACK (W	
R	F6HT-8040346-AB		2			HANDLE - OUTSIDE ASSIST S	
R	F7HT-8040374-GAZUCU		1			PANEL ASY LOWER BACK TRIM	
R	F6HT-8042006-AB		2			GLS BK WDO	
R	F6HT-8042084-AB		1			W/STRIP BACK WDO	
R	F6HT-8042085-AB		1			W/STRIP BACK WINDOW	
R	F6HT-8050202-MACSB		1			PANEL-ROOF (W/MARKER LAMP	
R	F6HT-8050290-AD		1			REINF RF PNL CTR RH	
R	F6HT-8050291-AD		1			REINF RF PNL CTR LH	
R	F6HT-8051496-AC		1			BRACKET - ROOF DOME LAMP	
R	F6HT-8051762-AA		2			CVR-RF DRP MLDG JNT	
R	F7HT-8051945-VBZUCP		1			PANEL - ROOF TRIM	
R	F6HT-8061602-AAZUDF		2			PLT DRVR ST BK SKID	
R	F4HT-9000014-BA		1			DECAL-WARNING INSTRUCTION	
R	F7HT-9012108-DA		1			FLR TRNS CVR PLTE ASSY	
R	F7HT-9024140-AAZUDF		1			ARM REST ASY DR TR RH	
R	F7HT-9024141-AAZUDF		1			ARM REST ASY DR TR LH	
R	F7HT-9040346-AA		1			HANDLE OUTSIDE ASSIST	
R	F6HT-9048196-N00000A		1			FBR - CUP HOLDER-SEAT	
R	F6HT-9053740-AA		6			PAD - ROOF OUTSIDE FRONT	
R	F6HT-9060012-BHA000B		1			(FBR) SEAT ASY-HI BK AIR	
R	F7HT-9060016-NR0FE0A		1			(FBR) SEAT ASY-FXD ECON P	
R	F7HT-9060050-NMLCFEA		1			(FBR) FRAME & CSHN ASSY-R	
R	F6HT-9060095-B00000A		1			FBR - SUPT ASY-SEAT W/SWI	
R	F6HT-9062900-NCAZUG7		1			FBR - COVER - MID BK SEAT	
R	F6HT-9062901-BGAZUG7		1			FBR - COVER - HI BK SEAT	
R	F7UB-15046A42-ACJAFS		1			PNL I/PNL RADO OPG FIN	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP
U	1998T35344002WVA30001		148H				LB23 199709
R	F1DB-54220A96-AA		2	F1DZ-5422023-A	RET ASY-FRT DR LK CYL		
R	F8VB-54234A44-AA		4		SPCR FRT DR WDO GL BRKT		
R	D9AB-54234A46-AA		4	D9AZ-54234A46-AA	RET ASY-DR WDO GL BRKT		
R	F2DB-54290C14-ACZUD3		2		HOOK COAT		
R	E43B-66280B62-AC		2	E43Z-66280B62-A	GRL ASY QTR VENT AIR		
R	F8HT-80022A38-AB		1		PANEL ASY - COWL SIDE FIN		
R	F8HT-80022A39-AB		1		PANEL ASY - COWL SIDE FIN		
R	F7HT-80024A60-CB		1		PANEL ASY-FRONT WHEEL HOU		
R	F7HT-80024A61-CB		1		PANEL ASY-FRONT WHEEL HOU		
R	F6HT-80025K90-ABZUDF		1		MOLDING ASY - FRONT BODY		
R	F6HT-80025K91-ABZUDF		1		MOLDING ASY - FRONT BODY		
R	F6HT-80041A16-AAZUCQ		1		BZL-VISOR ARM BRKT RH		
R	F6HT-80041A17-AAZUCQ		1		BZL-VISOR ARM BRKT LH		
R	F6HT-80042K50-AB		1		BRKT I/PNL REINF SUPT-RH		
R	F6HT-80044A12-ACZUEN		1		PNL I/PNL FIN LWR		
R	F7HT-80044A91-ABZUKA		1		PNL ASY I/PNL FIN UPR-LH		
R	F6HT-80044B78-BCZUKA		1		PNL ASY I/PNL FIN-RH		
R	F7HT-80044B79-AAZUEN		1		PNL ASY I/PNL FNSH LH		
R	F7HT-80044F36-AA		1		BRKT ASY - I/P TO CWL TOP		
R	F7HT-80044F48-AB		1		BRACE ASY - I/P TO DASH		
R	F7HT-80046A28-AA		1		BRKT ASY I/PNL LWR EXT-RH		
R	F7HT-80046A29-AA		1		BRKT ASY I/PNL LWR EXT-LH		
R	F6HT-80111A78-MBCSC		1		FBR - EXH BDY SD RH (SVO/		
R	F6HT-80111A79-MACSB		1		FBR - EXH BDY SD LH (W/O		
R	F6HT-80111B68-AA		2		GROMMET-REAR FLOOR OPENIN		
R	F6HT-80112A18-AB		1		CVR FRT FLR PAN WIR		
R	F7HT-80113A52-AA		1		SEAL ASY-FLR PN ACEL OPG		
R	F6HT-80130A92-ABZUKE		1		MOULDING - FLOOR TRIM		
R	F6HT-80211A54-AA		2		SLR-DR OPNG		
R	F6HT-80218A00-AB		1		ROD ASSY-DR LAT PSHBTN RH		
R	F6HT-80218A01-AB		1		ROD ASY-DR LAT PSHBTN LH		
R	F6HT-80237A04-BD		1		RH DOOR WATERSHIELD		
R	F6HT-80237A05-BD		1		LH DOOR WATERSHIELD		
R	F6HT-80243A52-BAZUDF		1		COVER ADJ SEAT BELT RH		
R	F6HT-80243A53-BAZUDF		1		COVER ADJ SEAT BELT LH		
R	F8HT-80278D48-AA		1		SEALER		
R	F8HT-80278D49-AA		1		SEALER		
R	F6HT-80278L00-MAN0A		1		FBR - AERO BDY SD - RH		
R	F6HT-80278L01-MAN0A		1		FBR - AERO BDY SIDE - LH		
R	F6HT-80312A84-AA		4		FASTENER - DOOR TRIM		
R	F6HT-80403A14-AB		1		REINF ASY-BRK PNL EXH LWR		
R	F6HT-80403D96-CB		2		PAD - OUTSIDE ASSIST HAND		
R	F6HT-80403E12-AB		1		REINF ASY-BK PNL EXH MTG		
R	F8HT-80404A88-AAZUDF		1		PNL ASY UPR BK TRIM (VNL-		
R	F6HT-80422A64-AA		1		EXT-BK WDO LWR FR-RH		

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
WVA30001	1998	148	T35344	002	LT8511	19970919	8.3L/275 DUMP

R	F6HT-80422A65-AA	1				EXTENSION - BACK WINDOW L	
R	F6HT-80423A40-MCCSC	1				FBR - TRIM BK PNL (HIGH)	
R	F7HT-80500A44-AA	4				SEAL-RF AIR DEFLT MNT FR	
R	F6HT-80502A82-MCH0B	1				FBR - HORN ROOF HOLES (DU	
R	F6HT-80502P84-MCH0D	1				FBR - AERO ROOF HOLES (PR	
R	F8HT-80517D20-AA	1				SEAL-RF SD RL OTR RR-RH	
R	F8HT-80517D21-AA	1				SEAL-RF SD RL OTR RR-LH	
R	F7HT-80519A58-AAZUEJ	1				ROOF CONSOLE - ASSEMBLY	
R	F6HT-80602B82-ABJADS	2				ADJ ASY-FRT SY SHLDR STRP	
R	F6HT-80602B90-AAJAEA	2				CVR SHLDR STRAP GUIDE ADJ	
R	F7HT-80611A72-EBZUDL	1				BELT SET - COMPLETE FRONT	
R	F7HT-80611A73-CCZUDL	1				BELT SET - COMPLETE FRONT	
R	F6HT-80611C34-AA	1				BRKT ASY-FRT SEAT BELT RE	
R	F6HT-80611C35-AA	1				BRKT ASY-FRT SEAT BELT RE	
R	F6HT-80625A89-AB	1				SUPT ASY-SEAT TO FLR HL D	
R	F6HT-80A02892-CB	2				BRKT - COWL TO PANEL TOP	
R	F6HT-90131K12-N00000A	1				FBR - COVER - AIR SUSP SE	
R	F6HT-90611A08-N00000A	1				FBR - HEADREST-SEAT BACK	
R	F6HT-90611A09-B00000A	1				FBR - HEADREST - SEAT BAC	
R	F6HT-90643A06-N00000A	1				FBR - MAP POCKET-SEAT BAC	
R	F6HT-90644A22-N00000A	1				FBR - ARMRESTS-DUAL SEAT	
R	F6HT-90644A23-B00000A	1				FBR - ARMRESTS - DUAL SEA	