Index

A

Abbreviations, List of 00.05
ABS, Hydraulic, Meritor WABCO 42.36
ABS, WABCO 42.30
Addresses, Component Manufacturers 00.00
Adjustable (tilt/telescoping) Steering Column 46.06
Air Brake Plumbing Diagrams, Cab 42.00
Air Brake Plumbing Diagrams, Cab and Chassis, Right-Hand-Drive Vehicles 42.37
Air Brake Plumbing Diagrams, Chassis 42.01
Air Brake Proportioning System 42.05
Air Brake System Troubleshooting 42.02
Air Cleaner 09.02
Air Compressor, Bendix AirMaster 13.00
Air Compressor, Cummins 13.04
Air Compressor, Holset SS191B 13.01
Air Compressor, Holset SS296 . . . . . 13.02
Air Compressor Drive Belt 01.00
Air Conditioner Performance Check, R–12 . . . . . 83.00
Air Conditioner Performance Check, R–134a 83.03
Air Conditioner Servicing, R–12 . . . . . 83.00
Air Conditioner Servicing, R–134a 83.03
Air Conditioner System Definitions, R–12 . . . . . 83.00
Air Conditioner System Definitions, R–134a 83.03
Air Conditioner Troubleshooting, R–12 . . . . . 83.00
Air Conditioner Troubleshooting, R–134a 83.03
Air Dryer, Bendix AD–9 . . . . . 42.06
Air Dryer, Rockwell WABCO System Saver 1000 . . . . . 42.09
Air Governor, Bendix D–2 . . . . . 13.03
Air Horn 60.04
Air Intake Ducting 09.00
Air Intake Heater, Cummins B Series 01.14
Air Lines and Fittings 42.03
Air Reservoir 42.07
Air Reservoir Automatic Drain Valve, Bendix DV–2 . . . . . 42.08
Air Restriction Gauge 54.08
Air Suspension, Cab Rear, Freightliner 60.05
Air Suspension, Cab Rear, Link CabMate 60.06
Air Suspension, Freightliner AirLiner 32.02
AirLiner Plus Suspension, Freightliner 32.09
AirLiner Suspension, Freightliner 32.02
Aisin Automatic Transmission 26.03
Alignment, Frame Rail 31.00
Alignment, Front Axle Wheel 33.00
Alignment, Rear Axle 35.00
Allison Automatic Transmission 26.01
Allison Automatic Transmission Wiring 54.11
All-Wheel-Drive Front Suspension 32.00
Alternator, Delco Remy CS–130 Series 15.00
Alternator, Delco Remy 21–SI Series 15.01
Alternator, Lestek Brute 190 and 200 . . . . . 15.09
Alternator, Nippondenso 15.04
Alternator Drive Belt 01.00
Ametek Coolant Temperature Gauge 54.12
Ametek Electronic Speedometer 54.06
Ametek Electronic Tachometer 54.05
Ametek Fuel Level Gauge 54.13
Ametek Transmission Temperature Gauge 54.16
Ametek Voltmeter 54.20
Anchorlok Tandem Brake Chamber 42.32
Angle-Ring Clutch, Spicer 25.00
Angle-Spring Clutch, Spicer 25.01
Antilock Braking System (ABS), Bendix 42.40
Antilock Braking System (ABS), Hydraulic, Rockwell WABCO 42.36
Antilock Braking System (ABS), WABCO 42.30
Antilock Braking System (ABS), WABCO D-Basic Hydraulic 42.42
Automatic Drain Valve, Air Reservoir, Bendix DV–2 . . . . . 42.08
Automatic Slack Adjuster, Crewson Brunner 42.34
Automatic Slack Adjuster, Gunite 42.28
Automatic Slack Adjuster, Haldex (SAB) 42.20
Automatic Slack Adjuster, Rockwell 42.19
Automatic Transmission, Aisin 26.03
Automatic Transmission, Allison 26.01
Automatic Transmission, Chrysler 26.02
Automatic Transmission Wiring, Allison 54.11
Axle Alignment, Rear 35.00
Axle Oil or Grease Seal, Front 33.01

Index

Axle Oil Seal, Rear 35.01

B

B Series Engine, Cummins 01.01
Battery, Maintenance-Free 54.03
Bearing, Wheel, Front Axle 33.01
Bearing, Wheel, Rear Axle 35.01
Belt, Drive 01.00
Belts, Seat and Tether 91.04
Bench Seat 91.00
Bendix AD–9 Air Dryer 42.06
Bendix Air Brake Proportioning System 42.05
Bendix Air Compressor 13.00
Bendix Antilock Braking System (ABS) 42.40
Bendix D–2 Air Governor 13.03
Bendix Double Check Valve 42.16
Bendix Driveline Parking Brake 42.14
Bendix DV–2 Automatic Drain Valve, Air Reservoir 42.08
Bendix E–12 Dual Brake Valve 42.04
Bendix Hydraulic Disc Brake 42.26
Bendix Manual Slack Adjuster 42.21
Bendix MV–3 Control Module 42.11
Bendix PP–DC Parking Brake Hand Valve 42.35
Bendix Pressure Relief Valve 42.27
Bendix QR–1 Quick Release Valve 42.12
Bendix QR–1C Quick Release Valve 42.39
Bendix Single Check Valve 42.15
Bendix TP–3 Tractor Protection Valve 42.17
Bendix TP–3DC Tractor Protection Valve 42.38
Block Heater, Engine 01.05
Blower Motor, Heater-A/C (R–12) 83.00
Blower Motor, Heater-A/C (R–134a) 83.03
Bosch Pin Slide Hydraulic Disc Brake 42.43
Bostrom 910 Seat 91.06
Bostrom Talladega Model 910 Seat 91.02
Bostrom Tube Frame Seat 91.03
Brake, Exhaust, Jacobs, Model EX3126B 01.16
Brake, Hydraulic Disc 42.26
Brake, Rockwell Cam-Master "Q" Series 42.23
Brake Chamber, Front, MGM "C" Series 42.33
Brake Chamber, Front, Midland 42.24
Brake Chamber, Rear, Anchorlok 42.32
Brake Chamber, Rear, MGM "E" and "TR" Series 42.25
Brake Chamber, Rear, MGM "L" Series 42.31
Brake Drum 42.22
Brake Plumbing Diagrams, Air, Cab 42.00
Brake Plumbing Diagrams, Air, Cab and Chassis, Right-Hand-Drive Vehicles 42.37
Brake Plumbing Diagrams, Air, Chassis 42.01
Brake System Troubleshooting, Air 42.02
Brake Valve, Dual, Bendix E–12 ..... 42.04
Bumper, FL112 ..... 31.03
Butterfly (engine access) Doors 88.00

C

C Series Engine, Cummins 01.07
Cab Air Brake Plumbing Diagrams 42.00
Cab Air Brake Plumbing Diagrams, Right-Hand-Drive Vehicles 42.37
Cab Door and Door Window 72.00
Cab Mount 60.00
Cab Painting and Touch-Up Painting 98.00
Cab Rear Air Suspension, Freightliner 60.05
Cab Rear Air Suspension, Link CabMate 60.06
Cable, Throttle, Cummins B and C Series Engine 30.00
Cable, Throttle, Mercedes-Benz OM 366LA Engine 30.01
Cam-Master "Q" Series Brake, Rockwell 42.23
Catalytic Converter Muffler 49.01
Chalmers 800 Series Suspension 32.06
Charge Air Cooler 09.01
Charging (A/C with R–12) 83.00
Charging (A/C with R–134a) 83.03
Chassis Air Brake Plumbing Diagrams 42.01
Chassis Air Brake Plumbing Diagrams, Right-Hand-Drive Vehicles 42.37
Chassis-Access Steps 47.00
Check Valve, Double, Bendix or Midland 42.16
Check Valve, Single, Bendix or Midland 42.15
Chrysler Automatic Transmission 26.02
Chrysler Fuel Pump Module 47.02
Circuit Breaker, Fuse, and Relay 54.01
Climate Control Two-Piston Refrigerant Compressor 83.02
Clutch Brake 25.06

Index

Clutch, Fan, Corsair/Horton EC450 On/Off 20.03
Clutch, Fan, Horton Advantage 20.04
Clutch, Fan, Kysor K22RA 20.05
Clutch, Fan Drive, Eaton Viscous 20.02
Clutch, Spicer Angle-Ring 25.00
Clutch, Spicer Angle-Spring 25.01
Clutch, Spicer Easy-Pedal 25.01
Clutch, Spicer Solo 25.01
Clutch, Valeo 25.04
Clutch Control, Hydraulic System 25.03
Clutch Control, Mechanical Linkage System 25.02
Clutch System, Sachs Hydraulic 25.07
Complete Painting or Touch-Up Painting 98.00
Component Manufacturers' Addresses 00.00
Compressor, Air, Bendix 13.00
Compressor, Air, Holset SS191B 13.01
Compressor, Air, Holset SS296 . . . . . 13.02
Compressor, Refrigerant, Climate Control 83.02
Compressor, Refrigerant, Sanden SD7 . . . . . 83.04
Compressor, Refrigerant, Zexel Swashplate 83.01
Condenser (A/C with R–12) 83.00
Condenser (A/C with R–134a) 83.03
Control Module, Bendix MV–3 . . . . . 42.11
Control Module, Kysor Engine-Shutdown 54.02
Control Module, Low Coolant Level 54.00
Conversion Chart, Metric/U.S. Customary 00.02
Coolant Temperature Gauge, Ametek 54.12
Cooling System Troubleshooting 20.00
Corsair/Horton EC450 On/Off Fan Clutch 20.03
Coupling Shaft, Driveline 41.00
Crewson Brunner Automatic Slack Adjuster 42.34
Crossmember, Frame 31.00
Cummins Air Compressor 13.04
Cummins B Series Engine 01.01
Cummins C Series Engine 01.07
Cummins Electronic Engine Wiring, ISB & ISC 54.15
Cummins Engine Throttle Control 30.00
Cummins M11 Engine 01.13
Cush-N-Aire Seat, National 91.01
Cush-N-Aire II Seat, National 91.05

D

Daytime Running Lights 54.04
DDEC II (Detroit Diesel Electronic Controls) 01.08
DDEC II and DDEC III Wiring 54.10
DDEC III (Detroit Diesel Electronic Controls) 01.08
Definitions, Air Conditioning System (R–12) 83.00
Definitions, Air Conditioning System (R–134a) 83.03
Delco Remy CS–130 Series Alternator 15.00
Delco Remy 21–SI Series Alternator 15.01
Delco Remy 28–MT Starter 15.02
Detroit Diesel Electronic Controls (DDEC II) 01.08
Detroit Diesel Electronic Controls (DDEC III) 01.09
Detroit Diesel Electronic Controls Wiring (DDEC II and DDEC III) 54.10
Detroit Diesel Series 50 Engine 01.10
Dimmer Switch, Headlight 54.04
Disc Brake, Hydraulic, Bendix 42.26
Disc Brake, Hydraulic, Bosch Pin Slide 42.43
Discharging (A/C with R–12) 83.00
Discharging (A/C with R–134a) 83.03
Dodge Magnum Engines Throttle Control 30.03
Dodge Magnum V-8 Engine 01.11
Dodge Magnum V-8 Engine Wiring 54.14
Door Glass Replacement 72.00
Door Latch 72.00
Door Removal, Installation, and Adjustment 72.00
Door Seal 72.00
Double Check Valve, Bendix or Midland 42.16
Drag Link, Steering 46.01
Drain Valve, Automatic, Bendix DV–2 . . . . . 42.08
Drilling Frame Rails 31.00
Drive Belt 01.00
Driveline, Steering, Spicer 46.00
Driveline, Steering, TRW 46.08
Driveline Component Servicing 41.00

Index

Driveline Parking Brake, Bendix 42.14
Driveline Parking Brake, Rockwell 42.18
Driveshaft 41.00
Drum Brake 42.22
Drum Brake, DURAPARK Hydraulic, Meritor 42.41
Dual Brake Valve, Bendix E–12 . . . . . 42.04
Ducting, Air Intake 09.00
DuPont Paint 98.00
Dura-Form Seats 91.07
DURAPARK Hydraulic Drum Brake, Meritor 42.41

E

Easy-Aire Seat, National 91.01
Easy-Pedal Spicer Clutch 25.01
Eaton (Fuller) Manual Transmission 26.00
Eaton Viscous Fan Drive 20.02
Electrical Circuit Numbers and Descriptions 54.01
Electrical Wiring Diagram (basic vehicle) 54.01
Electronic Controls, Detroit Diesel (DDEC II) 01.08
Electronic Controls, Detroit Diesel (DDEC III) 01.09
Electronic Engine Wiring, Cummins ISB & ISC 54.15
Electronic Engine Wiring, Detroit Diesel Series 50 . . . . . 54.10
Electronic Engine Wiring, Freightliner MBE900 . . . . . 54.18
Electronic Speedometer, Ametek 54.06
Electronic Tachometer, Ametek 54.05
Electronic Throttle Pedal, Williams 30.02
Emergency (jump) Starting 54.03
Engine, Caterpillar CFE 01.12
Engine, Cummins B Series 01.01
Engine, Cummins C Series 01.07
Engine, Cummins M11 . . . . . 01.13
Engine, Detroit Diesel Series 50 . . . . . 01.10
Engine, Dodge Magnum V-8 . . . . . 01.11
Engine, Freightliner MBE900 . . . . . 01.15
Engine, Mercedes-Benz OM 366LA 01.02
Engine Access (butterfly) Doors 88.00
Engine Block Heater 01.05
Engine Mount 01.03
Engine Shutdown and Warning System, Kysor 54.02
Engine Throttle Control, Cummins 30.00
Engine Throttle Control, Dodge Magnum 30.03
Engine Throttle Control, Mercedes-Benz 30.01
Engine Throttle Control, Williams 30.02
Engine Warning and Shutdown System, Kysor 54.02
Engine Wiring, Caterpillar CFE Series 54.09
Engine Wiring, Cummins ISB & ISC 54.15
Engine Wiring, Detroit Diesel Series 50 . . . . . 54.10
Engine Wiring, Dodge Magnum V-8 . . . . . 54.14
Engine Wiring, Freightliner MBE900 . . . . . 54.18
Essex Magnetic Switch 54.07
Ether Starting System 01.06
Evacuating (A/C with R–12) 83.00
Evacuating (A/C with R–134a) 83.03
Evaporator Coil (A/C with R–12) 83.00
Evaporator Coil (A/C with R–134a) 83.03
Exhaust Brake, Jacobs, Model EX3126B 01.16
Exhaust System 49.00
Expansion Valve (A/C with R–12) 83.00
Expansion Valve (A/C with R–134a) 83.03
Extended-Cab Side Windows 60.03
Exterior Lighting 54.04

F

Fan Belt 01.00
Fan Clutch, Horton Advantage 20.04
Fan Clutch, Horton DriveMaster 20.06
Fan Clutch, Horton EC450/Corsair 20.03
Fan Clutch, Kysor K22RA 20.05
Fan Drive, Eaton Viscous 20.05
Fasteners, Frame 31.00
Fasteners, Huckbolt 31.00
Fasteners, Metric 00.04
Fasteners, Threaded 00.04
Fiberglass-Reinforced-Plastic (FRP) Hood Repair 88.00
Fifth Wheel, Fontaine 5000 Series 31.02
Fifth Wheel, Fontaine 6000 and 7000 No-Slack II Series 31.07
Fifth Wheel, Fontaine H5092 Series 31.06

Fifth Wheel, Holland FW8 Series 31.04
Fifth Wheel, Holland 3500 Series 31.01
Fifth Wheel Mount, Sliding, Holland FW35/FW2535 . . . . . 31.05
Fire Pump, TwinFlow 90.00
Fittings and Lines, Air 42.03
Fixed Grille (radiator-mounted) 88.00
Flushing (A/C with R–12) 83.00
Flushing (A/C with R–134a) 83.03
Fontaine Fifth Wheel, 5000 Series 31.02
Frame Fasteners 31.00
Frame Repair 31.00
Freightliner AirLiner Plus Suspension 32.09
Freightliner AirLiner Suspension 32.02
Freightliner MBE900, Engine Wiring 54.18
Freightliner MBE900 Engine 01.15
Freightliner TufTrac Suspension 32.11
Freightliner Warning System 54.00
Freon (R–12) 83.00
Front Axle Oil or Grease Seal 33.01
Front Axle Wheel Alignment 33.00
Front Axle Wheel Hub and Bearing 33.01
Front Brake Chamber, MGM "C" Series 42.33
Front Brake Chamber, Midland 42.24
Front Suspension 32.00
FRP Hood 88.00
Fuel Level Gauge, Ametek 54.13
Fuel Line 47.00
Fuel Pump Module, Chrysler 47.02
Fuel System Priming 47.00
Fuel Tank 47.00
Fuel/Water Separator, Racor 47.01
Fuller Manual Transmission 26.00
Fuse, Circuit Breaker, and Relay 54.01

G

Gas Engine, Dodge Magnum 01.11
Glass, Door 72.00
Glass, Extended-Cab Side Windows 60.03
Glass, Rear Window 60.01
Glass, Windshield 60.01
Governor, Air, Bendix D–2 . . . . . 13.03
Grease Seal, Front Axle 33.01
Grille, Hood-Mounted (FRP Hood) 88.00
Grille, Hood-Mounted (Spray-Up Hood) 88.01
Grille, Radiator-Mounted (fixed) 88.00
GTD 4000–2 Quick Release Valve 42.13
Gunite Automatic Slack Adjuster 42.28

H

Haldex (SAB) Automatic Slack Adjuster 42.20
Half-Fender (FRP Hood) 88.00
Half-Fender (Spray-Up Hood) 88.01
Headlight 54.04
Headlight Aiming 54.04
Headlight Bucket (FRP Hood) 88.00
Headlight Bucket (Spray-Up Hood) 88.01
Headlight Dimmer Switch 54.04
Heater, Air Intake, Cummins B Series 01.14
Heater, Cab (A/C with R–12) 83.00
Heater, Cab (A/C with R–134a) 83.03
Heater, Engine Block 01.05
Heater, Oil Pan 01.04
Heater Troubleshooting (A/C with R–12) 83.00
Heater Troubleshooting (A/C with R–134a) 83.03
Hendrickson HAS Rear Suspension 32.10
Hendrickson RT/RTE and U/UE Suspension 32.04
Holland FW8 Series Fifth Wheel 31.04
Holland 3500 Series Fifth Wheel 31.01
Holland Sliding Fifth Wheel Mount, FW35/FW2535 . . . . . 31.05
Holset Air Compressor, SS191B 13.01
Holset Air Compressor, SS296 . . . . . 13.02
Hood Adjustment (FRP Hood) 88.00
Hood Adjustment (Spray-Up Hood) 88.01
Hood Liner 88.00
Hood Removal and Installation (FRP Hood) 88.00
Hood Removal and Installation (Spray-Up Hood) 88.01
Hood Repair (FRP Hood) 88.00
Hood Repair (Spray-Up Hood) 88.01
Hood Tilt-Assist (FRP Hood) 88.00
Hood Tilt-Assist (Spray-Up Hood) 88.01
Horn, Air 60.04
Horton Advantage Fan Clutch 20.04
Horton DriveMaster Fan Clutch 20.06
Horton EC450/Corsair Fan Clutch 20.03
Hub, Front Axle Wheel 33.01
Hub, Rear Axle Wheel 35.01

Index

Huckbolt Fasteners 31.00
Hydraulic ABS, Rockwell WABCO 42.36
Hydraulic Antilock Braking System (ABS), WABCO D-Basic 42.42
Hydraulic Clutch System, Sachs 25.07
Hydraulic Disc Brake, Bendix 42.26
Hydraulic Disc Brake, Bosch Pin Slide 42.43
Hydraulic Drum Brake, DURAPARK, Meritor 42.41

I

Imron 5000 Paint 98.00
Instrumentation Control Unit, Level I (ICU3) 54.17
Intake Ducting, Air 09.00
Interior Lighting 54.04

J

Jacobs Exhaust Brake, Model EX3126B 01.16
Jump (emergency) Starting 54.03

K

KBi Starting Fluid System 01.06
Kysor K22RA Fan Clutch 20.05
Kysor Warning and Engine Shutdown System 54.02

L

Leak Testing (A/C with R–12) 83.00
Leak Testing (A/C with R–134a) 83.03
Lestek Brute 190 and 200 Alternator 15.09
Light Bulb Replacement, Instrument Panel 54.04
Lighting System 54.04
Liner, Hood 88.00
Lines and Fittings, Air 42.03
Lines and Tanks, Fuel 47.00
Link CabMate Cab Rear Air Suspension 60.06
Lockbolt Fasteners 31.00
Luk Automotive Hydraulics LF 73 Power Steering Pump 46.09
Luk Automotive Hydraulics LF 80 Power Steering Pump 46.10

M

Magnetic Switch, Essex 54.07
Magnum V-8 Engine, Dodge 01.11
Magnum V-8 Engine Wiring, Dodge 54.14
Maintenance-Free Battery 54.03
Manual Slack Adjuster, Bendix 42.21
Manual Transmission 26.00
MBE900 Engine Wiring 54.18
Mercedes-Benz OM 366LA Engine 01.02
Metric Fasteners 00.04
Metric/U.S. Customary Conversion Chart 00.02
MGM Rear Brake Chamber, "E" and "TR" Series 42.25
MGM Rear Brake Chamber, "L" Series 42.31
MGM Service Brake Chamber, "C" Series 42.33
Midland Double Check Valve 42.16
Midland Service Brake Chamber 42.24
Midland Single Check Valve 42.15
Midland Trailer Brake Control Valve 42.29
Midship Bearing (driveline) 41.00
Mirrors 60.02
Mount, Cab 60.00
Mount, Engine 01.03
Muffler, Catalytic Converter 49.01
Muffler/Muffler Shield Replacement 49.00

N

National Cush-N-Aire Seat 91.01
National Cush-N-Aire II Seat 91.05
National Easy-Aire Seat 91.01
Nippondenso Alternator 15.04
Nippondenso Starter 15.03
Noise Liner, Hood 88.00

O

Oil Pan Heater 01.04
Oil Seal, Front Axle 33.01
Oil Seal, Rear Axle 35.01

P

Painting, Air Fairing (roof-mounted) 98.00
Painting, Vehicle 98.00
Parking Brake, Driveline, Bendix 42.14
Parking Brake, Driveline, Rockwell 42.18

Parking Brake Hand Valve, Bendix PP–DC 42.35
Parking Brake Valve, Sloan PV–1 . . . . . 42.10
Plumbing Diagrams, Air Brake, Cab 42.00
Plumbing Diagrams, Air Brake, Cab and Chassis, Right-Hand-Drive Vehicles 42.37
Plumbing Diagrams, Air Brake, Chassis 42.01
Power Steering Gear, Ross HFB 46.05
Power Steering Gear, Ross TAS 46.04
Power Steering Pump, Luk Automotive Hydraulics LF 73 . . . . . 46.09
Power Steering Pump, Luk Automotive Hydraulics LF 80 . . . . . 46.10
Power Steering Pump, TRW PS Series 46.07
Power Steering Pump, VT 7 Series 46.03
Pre-Delivery Information 00.01
Preform FRP Hood 88.00
Pressure Relief Valve, Bendix or Tramec 42.13
Priming, Fuel System 47.00
Proportioning System, Air Brake, Bendix 42.05
Protection Valve, Tractor 42.17
Purging (A/C with R–12) 83.00
Purging (A/C with R–134a) 83.03

Q

Quick Release Valve, Bendix QR–1 . . . . . 42.12
Quick Release Valve, Bendix QR–1C 42.39
Quick Release Valve, GTD 4000–2 . . . . . 42.13

R

R–134a Heater and A/C Systems 83.03
Racor Fuel/Water Separator 47.01
Radiator 20.01
Rear Axle Alignment 32.00
Rear Axle Oil Seal 35.01
Rear Axle Wheel Hub ad Wheel Bearing 35.01
Rear Brake Chamber, Anchorlok 42.32
Rear Brake Chamber, MGM "E" and "TR" Series 42.25
Rear Brake Chamber, MGM "L" Series 42.31
Rear Suspension, Watson & Chalin PusherTag 32.08
Rear Window 60.01
Receiver-Drier (A/C with R–12) 83.00
Receiver-Drier (A/C with R–134a) 83.03
Recycling R–12 Refrigerant 83.00
Recycling R–134a Refrigerant 83.03
Refrigerant Compressor, Climate Control 83.02
Refrigerant Compressor, Sanden SD7 . . . . . 83.04
Refrigerant Compressor, Swashplate 83.01
Refrigerant Compressor Drive Belt 01.00
Refrigerant R–12 Recycling 83.00
Refrigerant R–134a Recycling 83.03
Relay, Fuse, and Circuit Breaker 54.01
Reservoir, Air 42.07
Reyco 79KB Suspension 32.07
Right-Hand-Drive Vehicle Air Brake Plumbing Diagrams, Cab and Chassis 42.37
Rim Stud, Spoke Wheel, Front Axle 33.01
Rim Stud, Spoke Wheel, Rear Axle 35.01
Rockwell Automatic Slack Adjuster 42.19
Rockwell Cam-Master "Q" Series Brake 42.23
Rockwell Driveline Parking Brake 42.18
Rockwell WABCO System Saver 1000 Air Dryer 42.09
Ross HFB Power Steering Gear 46.05
Ross TAS Power Steering Gear 46.04
Rough Ride Diagnosis 32.03

S

Sachs Hydraulic Clutch System 25.07
Sanden SD7 Refrigerant Compressor 83.04
Seal, Front Axle Oil or Grease 33.01
Seal, Rear Axle Oil 35.01
Seat, Bench 91.00
Seat, Bostrom 910 . . . . . 91.06
Seat, Bostrom Talladega Model 910 . . . . . 91.02
Seat, Bostrom Tube Frame 91.03
Seat, Dura-Form 91.07
Seat, National Cush-N-Aire and Easy-Aire 91.01
Seat, National Cush-N-Aire II 91.05
Seat Belts 91.04
Separator, Fuel/Water, Racor 47.01
Series 50 Detroit Diesel Engine Wiring 54.10
Serpentine Drive Belt 01.00
Service Brake Chamber, MGM "C" Series 42.33

Index

Service Brake Chamber, Midland 42.24
Shutdown and Warning System, Kysor 54.02
Single Check Valve, Bendix or Midland 42.15
Slack Adjuster, Automatic, Crewson Brunner 42.34
Slack Adjuster, Automatic, Gunite 42.28
Slack Adjuster, Automatic, Haldex (SAB) 42.20
Slack Adjuster, Automatic, Rockwell 42.19
Slack Adjuster, Manual, Bendix 42.21
Sliding Fifth Wheel Mount, Holland FW35/FW2535 . . . . . 31.05
Sloan PV–1 Parking Brake Hand Valve 42.10
Solo Clutch, Spicer 25.01
Speedometer, Electronic, Ametek 54.06
Spicer Angle-Ring Clutch 25.00
Spicer Angle-Spring Clutch 25.01
Spicer Easy-Pedal Clutch 25.01
Spicer Solo Clutch 25.01
Spicer Steering Driveline 46.00
Spoke Wheel Stud Replacing, Front Axle 33.01
Spoke Wheel Stud Replacing, Rear Axle 35.01
Sprague Windshield Wiper System 82.00
Spray-Up Hood 88.01
Spring, Front Suspension 32.00
Spring, Single-Axle Suspension 32.01
Spring, Tandem-Axle Suspension 32.05
Starter, Delco Remy 15.02
Starter, Nippondenso 15.03
Steering Column, Fixed 46.02
Steering Column, Tilt/Telescoping 46.06
Steering Drag Link 46.01
Steering Driveline, Spicer 46.00
Steering Driveline, TRW 46.08
Steering Gear, Power, Ross HFB 46.05
Steering Gear, Power, Ross TAS 46.04
Steering Pump, Luk Automotive Hydraulics LF 73 . . . . . 46.09
Steering Pump, Luk Automotive Hydraulics LF 80 . . . . . 46.10
Steering Pump, TRW PS Series 46.07
Steering Pump, VT 7 Series 46.03
Steering Wheel 46.02
Suspension, Air, Cab Rear, Freightliner 60.05
Suspension, Chalmers 800 Series 32.06
Suspension, Freightliner AirLiner 32.02
Suspension, Freightliner AirLiner Plus 32.09
Suspension, Freightliner TufTrac 32.11
Suspension, Front 32.00
Suspension, Hendrickson HAS 32.10
Suspension, Hendrickson RT/RTE and U/UE 32.04
Suspension, Reyco 79KB 32.07
Suspension, Spring, Single-Axle 32.01
Suspension, Spring, Tandem-Axle 32.05
Suspension, Watson & Chalin PusherTag 32.08
Swashplate Refrigerant Compressor 83.01
Switch, Headlight Dimmer 54.04
Switch, Magnetic 54.07

T

Tachometer, Electronic, Ametek 54.05
Talladega Model 910 Seat, Bostrom 91.02
Tandem Brake Chamber, Anchorlok 42.32
Tandem Brake Chamber, MGM "E" and "TR" Series 42.25
Tandem Brake Chamber, MGM "L" Series 42.31
Tanks and Lines, Fuel 47.00
Tether Belts 91.04
Threaded Fasteners 00.04
Throttle Control, Cummins Engine 30.00
Throttle Control, Dodge Magnum Engine 30.03
Throttle Control, Electronic, Williams 30.02
Throttle Control, Mercedes-Benz Engine 30.01
Throttle Pedal, Electronic, Williams 30.02
Tilt/Telescoping Steering Column 46.06
Tire and Wheel 40.00
Torque Value Tables 00.04
Touch-Up Painting 98.00
Tractor Protection Valve, Bendix TP–3 . . . . . 42.17
Tractor Protection Valve, Bendix TP–3DC 42.38
Trailer Brake Control Valve, Midland 42.29
Tramec Pressure Relief Valve 42.13
Transmission, Allison Automatic 26.01
Transmission, Chrysler Automatic 26.02

Transmission, Manual 26.00
Transmission Temperature Gauge, Ametek 54.16
Transmission Wiring, Allison Automatic 54.11
Troubleshooting, Air Brake System 42.02
Troubleshooting, Basic Vehicle Wiring 54.01
Troubleshooting, Cooling System 20.00
Troubleshooting, Hydraulic Brake System 42.26
Troubleshooting, Power Steering Gear 46.04
TRW PS Series Power Steering Pump 46.07
TRW Steering Driveline 46.08
Tube Frame Seat, Bostrom 91.03
Turn Signal Switch 54.04
TwinFlow Fire Pump 90.00

U

U-Joint (driveline) 41.00
U.S. Customary/Metric Conversion Chart 00.02

V

Valeo Clutch 25.04
Vehicle Identification Numbering (VIN) System 00.03
Vehicle Painting 98.00
Vehicle Receipt, Storage, and Pre-Delivery Information 00.01
Vent Window Removal and Installation 72.00
Viscous Fan Drive, Eaton 20.02
Voltmeter, Ametek 54.20

W

WABCO Antilock Braking System (ABS) 42.30
WABCO D-Basic Hydraulic Antilock Braking System (ABS) 42.42
WABCO Hydraulic Antilock Braking System (ABS), Rockwell 42.36
Warning and Shutdown System, Kysor 54.02
Warning System, Freightliner 54.00
Washer, Windshield 82.00
Water Pump Drive Belt 01.00
Watson & Chalin PusherTag Suspension 32.08
Welding Frame Rails 31.00
Wheel Alignment, Front Axle 33.00
Wheel and Tire 40.00
Wheel Bearing, Front Axle 33.01
Wheel Bearing, Rear Axle 35.01
Wheel Hub, Front Axle 33.01
Wheel Hub, Rear Axle 35.01
Wheel Stud, Front Axle 33.01
Wheel Stud, Rear Axle 35.01
Williams Electronic Throttle Pedal 30.02
Window, Side, Extended-Cab 60.03
Window Replacement (door, vent) 72.00
Windshield and Seal Replacement 60.01
Windshield Wiper/Washer 82.00
Wire Number Code 54.01
Wiring Diagram (basic vehicle) 54.01
Wiring Diagram, Allison Automatic Transmission 54.11
Wiring Diagram, Cab Heater-A/C with R–12 . . . . . 83.00
Wiring Diagram, Cab Heater-A/C with R–134a 83.03
Wiring Diagram, Caterpillar CFE Series 54.09
Wiring Diagram, Cummins ISB & ISC 54.15
Wiring Diagram, Detroit Diesel Series 50 . . . . . 54.10
Wiring Diagram, Dodge Magnum V-8 Engine 54.14
Wiring Diagram, Freightliner Warning System 54.00
Wiring Diagram, Kysor Warning and Shutdown System 54.02
Wiring Diagram, Starting System 54.07
Wiring Diagram, Vehicle Lighting 54.04
Wiring Troubleshooting (basic vehicle) 54.01

Y

York Swashplate Refrigerant Compressor 83.01