MASTER INDEX.....01
GEN INFO WARRANTY PLATE.....01
ALPHA INDEXES
ACCESS.....02
CHASSIS.....02
PAINT.....02
WHEEL-BRAKE
1000.....03
P/L 11.1....03
P/L 11.2....04
2000.....04
2201.....05
2300.....07
20.1 F/BRK..05
22.1 R/BRK..06
23.1 BSTR...07
26.1 P/BRK..08
ILLUS.....09
FRT AXLE STR
3000.....14
35.1 S/GEAR.15
35.2 P/S CYL15
3600.....15
ILLUS.....16
CHASSIS 4000 - 5999 TRANS #2
CHASSIS 6000 - 9999 TRANS #3
CHASSIS 10000-19999 BODY SOFT TRIM CROSS REF TRANS #4
DSO APPEARS IN FPS 8473-M

YEAR	MODEL/RESTRICTIONS	PART NUMBER	DESCRIPTION	QTY.
3513	SEAL (STEERING COLUMN WEATHER) — Cont'd			
73/	L-LN-LNT-LT-LTS 600/900 - - M/T	D3HZ 3513-A		1
73/	L-LT-LTS 900 - - M/T			1
73/	LN-LNT 900 - - 8 cyl. gas, 6 cyl., Cum. diesel, 6 cyl. Detroit diesel and M/T			1
				1
73/	L-LN-LNT-LT-LTS600/900 - - T/M	D3HZ 3513-B		1
73/	LN-LNT900 - - 8 cyl. Cum. and Detroit diesel and M/T	D3EZ 3513-A		1
78/	P600 - - M/S	★ D8HZ 3513-A	Not replaced	1
3514	Refer to group 3509			
3C514	Refer to P/S Cylinder Parts Lists Section 35.2, page 1			
3K514	Refer to P/S pump T.S. L. Chart or Model Application chart in section 36.1			
3C515	Refer to Steering Gear Section 35.1, page 1			
3C516	HOUSING ASSY. (POWER STEERING DRAG LINK CONTROL VALVE & SPOOL)			
73/	C-CT600/900	C6TZ 3C516-A		1
3517	BEARING ASSY. (STEERING COLUMN)			
73/	B-F600/880	D1TZ 3517-A	Upper-retainer and bearing assy.-incl. retainer, bearing, seal and snap ring	1
73/	C-CT600/900	C3DZ 3517-A	Upper bearing	1
		C3TZ 3517-B	Lower bearing	1
73/	L-LN-LNT-LT-LTS600/900	DOHZ 3517-A	Upper-7/8" I.D. x 1 21/32" O.D. x 7/16" thick-#LL 52949 & #LL 52510	1
		DOHZ 3517-B	Lower-1" I.D. x 2" O.D. x 9/16" thick-#LL 44643 & #LL 44610	1
78/	P600	C3TZ 3517-B	Upper	1
73/77	W-WT900	C3DZ 3517-A	Upper	1
		C8HZ 3517-A	Lower	1
78/	CL-CLT900	C3DZ 3517-A	Upper	1
		C8HZ 3517-A	Lower	1
3C517	WASHER (POWER STEERING CONTROL VALVE CENTERING SPRING)			
73/	C-CT600/900	C1TT 3C517-A		2
3518	SLEEVE (STEERING COLUMN TUBE BEARING)			
73/	C-CT600/900	C4TZ 3518-B	7/8" I.D. x 1 1/8" O.D.	1
78/	CL-CLT900	C4TZ 3518-B	Upper	1
		C8HZ 3518-A	Lower	1
		371916-S	(XX-242-G)-Flat washer(3518 to 3520)-7/8" I.D. x 1 1/4" O.D. x 1/16" thick	1
78/	P600	B1AZ 3518-A		1
73/77	W-WT900	C4TZ 3518-B	Upper	1
		C8HZ 3518-A	Lower	1
3C518	SPACER (POWER STEERING CONTROL VALVE CENTERING SPRING)			
73/	C-CT600/900	C1TT 3C518-A	1/2" O.D. x 3/8" I.D. x 1 1/16" long	1
3520	SPRING (STEERING COLUMN UPPER BEARING)			
73/	C600/750 - - P/S	C4TZ 3520-A		1
73/	C800/900(9 1/2" frame) - - P/S			1
73/	C600/750 - - M/S	C7TZ 3520-A		1
73/	C800/900(9 1/2" frame) - - M/S			1
73/	C800/900(9 3/4" frame)			1
78/	CL-CLT900			1
73/	CT800/900			1
73/77	W-WT900			1
		371681-S8	(XX-252)-washer (spring retaining)-7/8" dia.	1
78/	P600	BM 3520		1
3C520	Refer to group 3A719			
3524	Refer to Steering Gear Parts Lists Section 35.1, page 1			
3524	Refer to group 3A526			
3C524	PLATE (POWER STEERING DRAG LINK VALVE)			
73/	C-CT600/900	C1TT 3C524-A	Control valve stop-1" I.D. x 2 5/8" O.D. x 1/8" thick	1

COPYRIGHT © 1987 — FORD MOTOR COMPANY — DEARBORN, MICHIGAN