MASTER INDEX 01
GEN INFO....01
ALPHA INDEXES
ACCESS.....02
CHASSIS.....02
REAR AXLE
SEC 40.....03
SEC 40.1
P/LISTS.....04
4000.....06
ILLUS.....22
DRIVESHAFT
SEC 41-46...06
SEC 46.1-46.1A
SEC 46.2-46.5
DRIVE & COUP COMPONENTS
PARTS LIST..07
ILLUS.....22
COUPLING SHAFT & INTERSHAFT
SEC 48
4800.....17
SEC 48.1-48.6
.....18
ILLUS.....22
FRAME-SPRING EXHAUST
5000.....23
5300.....25
ILLUS.....26
CHASSIS 6000-9999 TRANS #3
CHASSIS 10000-19999 BODY-S/TRIM VENDOR/FORD CROSS REF TRANS #4
DSO APPEARS IN FPS 8473-M

1973/79 TRUCK SERIES 600/900

4602 SHAFT ASSY.-DRIVE

APPLICATION CHART

TRANSMISSION SPEED	TRANSMISSION MODEL	ENGINE TYPE	ENGINE CYL.	ENGINE C.I.D. OR MODEL	REAR AXLE MFR. ▲	REAR AXLE MODEL	WHEEL-BASE (INCHES)	YEAR	TYPE ▲	SIZE (INCHES) A	SIZE (INCHES) B	NOTE	PART NUMBER ▲	▲ CODE YOKE	▲ CODE U-JOINT FRNT.	▲ CODE U-JOINT REAR
NOTE: ▲ REFER TO PAGE 1 OF SECTION 46.1 FOR AN EXPLANATION OF THE CHART AND THE CODES SHOWN.																
LT800 SERIES — Cont'd																
WITHOUT AUXILIARY TRANSMISSION																
13	Fuller 613	D	8	522,573 636 Cat.	E R	D440P SLHD,SQHD	150	74/79	4	37 1/32	4	24	★ D3HA 4602-AAA	57	40	40
							150	74/77	4	35 17/32	4	28	★ D3HA 4602-ZA	57	40	40
							162	74/79	4	49 1/32	4	24	★ D3HA 4602-AJA	57	40	40
							162	74/77	4	46 1/32	4	28	★ D3HA 4602-AGA	57	40	40
							174		4	61 1/32	4	24	★ D3HA 4602-AUA	57	40	40
							174		4	58 1/32	4	28	★ D3HA 4602-ASA	57	40	40
							186		4	28 1/32	4	24	★ C6TZ 4602-BH	57	40	40
							186		4	25 1/32	4	28	★ C6TZ 4602-BE	57	40	40
							204		4	37 1/32	4	24	★ D3HA 4602-AAA	57	40	40
							204		4	34 1/32	4	28	★ D3HA 4602-YA	57	40	40
							222		4	58 1/32	4	24	★ D3HA 4602-ASA	57	40	40
							222		4	56 17/32	4	28	★ D3HA 4602-ARA	57	40	40
							236		4	59 17/32	4		★ D3HA 4602-ATA	57	40	40
		D	8	V-555 Cum.	E	34D,42D	150	74/77	4	40 1/32	4	24	★ D3HA 4602-ACA	57	40	40
							150		4	38 17/32	4	28	★ D3HA 4602-ABA	57	40	40
							162		4	52 1/32	4	24	★ D3HA 4602-ALA	57	40	40
							162		4	49 1/32	4	28	★ D3HA 4602-AJA	57	40	40
							174		4	64 1/32	4	24	★ D3HA 4602-AYA	57	40	40
							174		4	61 1/32	4	28	★ D3HA 4602-AUA	57	40	40
							186	74/75	4	32 17/32	4	24,50	★ C6TZ 4602-BR	57	40	40
							186	75/77	4	32 17/32	4	24,51	★ D3HA 4602-VA	57	40	40
							186	74/77	4	30 1/32	4	28	★ C7TZ 4602-CT	57	40	40
							204		4	40 1/32	4		★ D3HA 4602-ACA	57	40	40
							222		4	64 1/32	4	24	★ D3HA 4602-AYA	57	40	40
							222		4	61 1/32	4	28	★ D3HA 4602-AUA	57	40	40
							236		4	62 17/32	4		★ D3HA 4602-AVA	57	40	40
					E	38D	150	74/77	4	40 1/32	4	24	★ D3HA 4602-ACA	57	40	40
							150		4	37 1/32	4	28	★ D3HA 4602-AAA	57	40	40
							162		4	52 1/32	4	24	★ D3HA 4602-ALA	57	40	40
							162		4	49 1/32	4	28	★ D3HA 4602-AJA	57	40	40
							174		4	64 1/32	4	24	★ D3HA 4602-AYA	57	40	40
							174		4	58 1/32	4	25	★ D3HA 4602-ASA	57	40	40
							174		4	61 1/32	4	28	★ D3HA 4602-AUA	57	40	40
							186		4	32 17/32	4	24	★ C6TZ 4602-BR	57	40	40
							186		4	30 1/32	4	28	★ C7TZ 4602-CT	57	40	40
							204		4	41 17/32	4		★ D3HA 4602-ADA	57	40	40
							222		4	62 17/32	4	24	★ D3HA 4602-AVA	57	40	40
							222		4	61 1/32	4	28	★ D3HA 4602-AUA	57	40	40
					E	34,38,42D	150	78/79	4	40 1/32	4		★ D3HA 4602-ACA	57	40	40
							162		4	52 1/32	4		★ D3HA 4602-ALA	57	40	40
							174		4	64 1/32	4	24	★ D3HA 4602-AYA	57	40	40
							174		4	61 1/32	4	28	★ D3HA 4602-AUA	57	40	40
							174		4	58 1/32	4	25	★ D3HA 4602-ASA	57	40	40
							186		4	32 17/32	4	24	★ D3HA 4602-VA	57	40	40

NOTE 24 – With 50" walking beam.
NOTE 25 – With 60" walking beam.
NOTE 28 – With 54" walking beam.
NOTE 50 – "Before Ser. W00,001"
NOTE 51 – "From Ser. W00,001"

SECTION 46.4 - Contd
HOW TO FIND DRIVESHAFT PARTS....07-02
U/JOINT & YOKE CODE C/REF.....07-03
T.S.L. C/REF INDEX.....07-07
APPLICATION CHART.....07-36
DRIVE & COUP SHAFT COMPONENTS PARTS LISTS.....07-37