GEN INFO...01
ALPHA INDEXES
ACCESS.....02
CHASSIS....02
PAINT.....02
WHEEL-BRAKE
1000.....03
11.1,11.2..03
2000-20.1..04
22.1.....05
22.2.....06
2300-23.1..06
26.1.....07
ILLUS.....08
FRONT AXLE
STEERING
3000.....13
35.1.....13
35.2.....14
3600-36.1..14
ILLUS.....15
REAR AXLE
SEC 40.....17
SEC 40.1...18
4000.....22
ILLUS.....27
DRIVESHAFT &
COUPLINGSHAFT
4600.....23
SEC 46.1...23
SEC 46.1A..24
SEC 46.2-3.25
ILLUS.....27
COUPLING
SHAFT &
INTERSHAFT
4800.....25
SEC 48.1-6.25
ILLUS.....27
5000 THRU
9999
TRANS #2
10000 THRU
SHEET METAL
TRANS #3
D50-VDR TO
FORD-C/REF
TRANS #3

Components for complete shaft assemblies are also available for service when the service part number for the complete shaft assembly is known. The part number of the shaft sub-assembly and related components may be found in the Drive and Coupling Shaft Component Parts List in Section 46.1A

COUPLING SHAFT AND INTERMEDIATE COUPLING SHAFT APPLICATION CHART INDEX

MODEL	SHAFT	R - C	MODEL	SHAFT	R - C
B600	Coupling shaft	26-01	F600	Coupling shaft	26-02
	Intermediate shaft	26-20		Intermediate shaft	26-21

COUPLING SHAFT and INTERMEDIATE COUPLING SHAFT PARTS LISTS

Notes:
$ Not included in 4817 assy. @ Use 383952-S bolt (7/8"-14 x 1 1/2")
† Use 383951-S2 bolt (3/4"-16-1 1/2") and 34797-S2 lockwasher △ Includes bearing, retainer and sleeve
% Use 304771-S2 bolt (3/4"-16-1 1/2") and 34797-S2 lock washer
@ Use 383951-S2 bolt (3/4"-16-1 1/2")
NOTE 1 - Coupling shaft does not require support bearing collar - (discard)
NOTE 2 - Coupling shaft requires one of the two bearing baffles - (discard one only)

QTY.	PART NUMBER	DESCRIPTION
		PARTS LIST NO. 30
1	B4TZ 4635-G	Universal joint
1	D4TZ 4800-C	Support Assy. (Center Bearing)
1	$B5Q 4865-B	Universal joint flange (rear)
		PARTS LIST NO. 46
1	C1TZ 4635-A	Universal joint
1	D4TZ 4800-C	Support Assy. (Center Bearing)
		PARTS LIST NO. 48
1	C5TZ 4635-G	Universal joint
1	C5TZ 4805-A	Bearing baffle
1	D0TZ 4808-A	Center support
1	△D0TZ 4840-A	Bearing (coupling shaft support)
		PARTS LIST NO. 55
1	★C1TT 4523-A	Retainer
	r/b D4TZ 4800-G	
1	D3TZ 4635-B	Universal joint
1	D4TZ 4800-G	Support Assy. (Center Bearing)
1	C6TZ 4865-B	Universal joint flange (rear)
		PARTS LIST NO. 59
1	C1TZ 4635-A	Universal joint
1	D4TZ 4800-C	Support Assy. (Center Bearing)
1	C1TT 4865-B	Universal joint flange (rear)
		PARTS LIST NO. 62
1	C5TZ 4635-G	Universal joint
1	C5TZ 4805-A	Bearing baffle
1	D0TZ 4808-A	Center support
1	△D0TZ 4840-A	Bearing (coupling shaft support)
1	C8HZ 4865-A	Flange yoke
		PARTS LIST NO. 72
1	D3HZ 4635-D	Universal joint
1	D4TZ 4800-G	Support assy. (center bearing)
		PARTS LIST NO. 73
1	D2HZ 4635-A	Universal joint
1	D3HZ 4637-A	Washer
1	D4TZ 4800-J	Support Assy. (Center Bearing)
2	★[illegible] 4805-A	Bearing baffle- r/b D4TZ 4800-J
1	★[illegible] 4808-A	Center support-r/b D4TZ 4800-J
1	★C8[illegible] 4826-A	Support sleeve - r/b D4TZ 4800-J
1	★C8TZ 4840-A	Bearing (coupling shaft support)- r/b D4TZ 4800-J
1	D2HZ 4865-A	Flange yoke

QTY.	PART NUMBER	DESCRIPTION
		PARTS LIST NO. 80
1	D3TZ 4635-B	Universal joint
1	D4TZ 4800-G	Support Assy. (Center Bearing)
1	C6TZ 4865-B	Flange yoke
		PARTS LIST NO. 81
1	D2HZ 4635-A	Universal joint
1	D3HZ 4637-A	Washer
1	D4TZ 4800-J	Support Assy. (Center Bearing)
1	D2HZ 4865-A	Flange yoke
		PARTS LIST NO. 90
1	B6TZ 4635-B	Universal joint
1	D5TZ 4800-A	Support Assy. (Center Bearing)-NOTE 2
1	D4HZ 4805-A	Bearing Baffle-Also Serviced In 4800 Assy.
1	D4HZ 4805-B	Bearing Baffle (Collar)-Also Serviced in 4800 assy.
		PARTS LIST NO. 93
1	D3HZ 4635-D	Universal joint
1	D4TZ 4800-G	Support Assy. (Center Bearing)
1	D0HZ 4865-C	Flange yoke
		PARTS LIST NO. 95
1	D3TZ 4635-A	Universal joint
1	★D4TZ 4800-E	Support assy. (center bearing))
	r/b D9HZ 4800-A	
1	D9HZ 4865-A	Flange yoke
1	D6HZ 4637-A	Washer
		PARTS LIST NO. 97
1	D3HZ 4635-B	Universal joint
1	★D4TZ 4800-E	Support assy. (center bearing)
	r/b D9HZ 4800-A	
1	$@D0HZ 4865-B	Universal joint flange (rear)
		PART LIST NO. 98
1	B6TZ 4635-B	Universal joint
1	B5QH 4637-A	Washer
1	D5TZ 4800-A	Support assy. (center bearing)-NOTE 1
2	D4HZ 4805-A	Bearing baffle-also serviced in 4800 assy.
1	†D4TZ 4865-A	Flange yoke
		PARTS LIST NO. 99
1	B4TZ 4635-H	Universal joint
1	D4TZ 4800-C	Support assy. (center bearing)

COPYRIGHT © 1985 FORD MOTOR COMPANY DEARBORN, MICHIGAN

ROW 25

46.1A Contd
E1HT 4817-CHA.01
E4HT 4817-KHA.05
E7HT 4817-FFA.11
D2HZ 4964-C...13

SEC 46.2-46.3
DRIVESHAFT APPL
B600.....16
F600.....20
GF600.....38
CF700.....38

SEC 48
4800..42
4851..45
4859..51
4881..53

SECTION 48.1 - 48.6
COUPLING SHAFT & INTERM SHAFT
GENERAL INFO.....59
CODE/CROSS REF...60
COUP SHAFT TYPES.62
PARTS LIST.....63
TSL INDEX.....23-30
4817 APPL CHART.26-01
4886 APPL CHART.26-20